



EL22XPV

Order No.	Model No.	Tons	SEER2 (Up To)	H x W x D
Variable-Capacity Cooling/Heating - Lennox [®] Communicating Control - DC Inverter Control - Quantum™ Aluminum Coil				
23K61	EL22XPV-024-230	2	22.00	39 x 35.5 x 39.5
23K62	EL22XPV-036-230	3	21.50	39 x 35.5 x 39.5
23K63	EL22XPV-048-230	4	19.50	45 x 35.5 x 39.5
23K64	EL22XPV-060-230	5	19.00	45 x 35.5 x 39.5


XC20

Order No.	Model No.	Tons	SEER2 (Up To)	H x W x D
Variable-Capacity Cooling/Heating - R-410A - Lennox [®] Communicating Control - DC Inverter Control				
11X57	XP20-024-230	2	19.00	39 x 35.5 x 39.5
18C35	XP20-036-230	3	20.00	39 x 35.5 x 39.5
11X63	XP20-048-230	4	18.40	45 x 35.5 x 39.5
11X64	XP20-060-230	5	18.60	45 x 35.5 x 39.5

NOTE - A Lennox[®] Communicating Thermostat (S40 or S30) and a variable-speed Lennox[®] Communicating Furnace or Air Handler is required with the XC20 for a complete communicating system. All components must be ordered separately.

EL18XPV

Order No.	Model No.	Tons	SEER2 (Up To)	H x W x D
Variable-Capacity Cooling/Heating - Lennox [®] Communicating Control - DC Inverter Control - Quantum™ Aluminum Coil				
19U06	EL18XPV-024-230	2	21.60	35 x 27 x 28
19U07	EL18XPV-036-230	3	19.40	35 x 27 x 28
19U08	EL18XPV-048-230	4	18.40	45 x 30.5 x 35
19U09	EL18XPV-060-230	5	17.60	45 x 30.5 x 35



EL17XP1

Order No.	Model No.	Tons	SEER2 (Up To)	H x W x D
R-410A - Quantum™ Aluminum Coil				
23A01	EL17XP1-018	1.5	17.00	45 x 30.5 x 35
23A02	EL17XP1-024	2	17.00	45 x 30.5 x 35
23A03	EL17XP1-030	2.5	16.20	35 x 30.5 x 35
23A04	EL17XP1-036	3	16.80	35 x 35.5 x 39.5
23A05	EL17XP1-042	3.5	15.60	39 x 35.5 x 39.5
23A07	EL17XP1-048	4	15.80	39 x 35.5 x 39.5
23A09	EL17XP1-060	5	14.70	45 x 35.5 x 39.5