



**TD = TIME DELAY (OPT.)
TR = TRANSFORMER
BR = BLOWER RELAY
MTR = BLOWER MOTOR
CAP = MOTOR CAPACITOR
GND = GROUND
CONNECTION
F1 = FUSE 3 AMP, BLADE TYPE, 32V