Lock
up
Seat Depth Adjustment Move Lever Forward
Seat Height Adjustment Move Lever Up and Down
Back Angle Adjustment Move Lever Backward
Back Tilt Tension Adjustment