

## User Notice PS-MaXX Adapter

April, 2023

PLEASE READ NOW AND TAKE ACTION

**MSA Corporate Center**  
1000 Cranberry Woods Drive  
Cranberry Township, PA 16066  
800.MSA.2222  
www.MSAafety.com

**Dear MSA Customer,**

MSA is issuing this User Notice to inform you of an additional inspection procedure regarding usage of the PS-MaXX adapter.

MSA has received a report of a broken white seal ring used on a PS-MaXX adapter in conjunction with a G1 facepiece. A broken seal ring may result in potential exposure to the ambient atmosphere of the user. **MSA has only received one report of this condition. However, it is necessary that you perform the actions outlined in this notice.**

### Inspection Procedure

This inspection procedure must be performed on your entire stock upon receipt of this notice and prior to each connection of the PS-MaXX adapter to the facepiece, for continued proper operation of the white seal ring.

1. If connected to a G1 facepiece, disconnect the PS-MaXX adapter from facepiece.
2. Visually inspect the white sealing of the adapter for any visual imperfections (figure 1)
  - a. If any visual damage is found, remove the unit from service, quarantine the unit, and contact MSA for a replacement sealing.
  - b. If no visual damage is found, the adapter may be returned to service.



Figure 1 – PS-MaXX adapter and seal ring

MSA has also updated the PS-MaXX instruction sheet (10042489) to include inspection of the sealring and adapter, available here: ([Instruction Sheet for Filter Connection PS-MaXX](#)). Please download and replace your manuals with the latest update. This inspection must be performed prior to each connection of the PS-MaXX adapter to the facepiece.



### **MSA Customer Service Contact Information**

If you have any questions regarding this User Notice and for any required replacement seal rings, please email us at [ProductUserNotice@msasafety.com](mailto:ProductUserNotice@msasafety.com) or contact your local MSA customer service representative.

We apologize for any inconveniences that this may cause; however, your safety and continued satisfaction with our products is important to us.

Issued by: Adam Troup  
Product Safety Manager

**MSA Corporate Center**  
1000 Cranberry Woods Drive  
Cranberry Township, PA 16066  
800.MSA.2222  
[www.MSAsafety.com](http://www.MSAsafety.com)