## Product Information News

## August 29, 2008

## POSICHEK SOFTWARE UPGRADE

This PIN Article addresses an upgrade to the MSA version of the PosiChek Software. This new version improves on versions 3.22 P and Beta 3.24 P. The new version is version 3.26 P.

The table below summarizes the changes to this software.

Add the PR14 <sup>™</sup> First Stage Regulator Test Configuration	Provides the option for PR14 First Stage Regulator testing.
Improve the Heads-Up Display Test	Modified the tolerances for the heads-up display test criteria.
Incorporate New Audi-Larm Ring Down Set Point	To assist in testing, MSA raised the ring down set point from 150 psig to 175 psig. This provides a greater margin for acceptance while maintaining the NIOSH requirements.
Add the FireHawk® M7 Air Mask and M7 Responder Test Configurations	The following test configurations and criteria have been added: FireHawk M7 Air Mask, 2216; FireHawk M7 Air Mask, 2216 PR14 First Stage Regulator; FireHawk M7 Air Mask, 3000; FireHawk M7 Air Mask, 3000 PR14 First Stage Regulator; FireHawk M7 Air Mask, 4500; FireHawk M7 Air Mask, 4500 PR14 First Stage Regulator. FireHawk M7 Responder® Air Mask, 2216;
	FireHawk M7 Responder Air Mask, 3000; FireHawk M7 Responder Air Mask, 4500.
Add PremAire® Escape Test Configuration	Test configuration and criteria were added.
Implement New PR14 First Stage Regulator Test Criteria	The following are the PR14 First Stage Regulator pressure levels as documented in the previous version of the MSA PosiChek Software: MMR 2216 PR14 First Stage Regulator: 1900 – 2300 MMR 3000 PR14 First Stage Regulator: 2600 – 3000 MMR 4500 PR14 First Stage Regulator: 4100 – 4500 The new version 3.26 P has new PR14 First Stage Regulator pressure levels consistent with the standard MMR First Stage Regulator. For the PR14 First Stage Regulator, the new criteria are as follows: MMR 2216 PR14 First Stage Regulator: 1825 - 2250 MMR 3000 PR14 First Stage Regulator: 2475 – 3000 MMR 4500 PR14 First Stage Regulator: 3712 – 4500

PosiChek SW is compatible with Windows Vista Operating System.

Please visit the following website to download a free upgrade to the MSA PosiChek Software version 3.26 P.

http://www.biodownloads.com/html/posi\_msa\_us.htm

Note: A licensed 32-bit version of the MSA PosiChek Software is required for the free upgrade.

For More Information, call 1-800-MSA-2222 or Visit Our Website at www.MSAnet.com

