

MSA PFLs Twin Connection

Technical Brief FP-PC032



The MSA line of Mini and standard PFLs may be used in the twin configuration either by purchasing a twin configuration complete or by joining two individual units, of the same type, via a TwinLink connector – Part Numbers 63900-04 or 64900-00 or carabiners – Part Numbers 10089205, 10147792 or 62207-63.

Regarding usage of other connectors, MSA recommends that a carabiner with a triple action gate be used to join two units. However, the double-locking carabiners listed above may also be used. Please refer to the instructions provided with each unit for the preferred connection procedure to the full body harness.

Finally, provided the proper carabiner is used as described above, it is also acceptable to attach both units via a single carabiner directly to the dorsal d-ring of the user's harness.