
IMPORTANT NOTICE:
HARDWARE PACKAGE IS ATTACHED ON THE BOTTOM OF SEAT CUSHION.

MODEL: B9479


(1)X1



(2)X1(L)X1(R)




(3)X1




(A)*4		M8*36 Sled Base Screws
(B)*4		M8*45 Arm Screws
(C)*1		Allen Key

1



2



Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.



Customer Service Hotline: 1-800-593-1888 For further assembly instructions, please visit our website at www.bosschair.com

09/15