



GENERAL MONITORS

Protection for life.

MODEL TA102A

Zero Two Series
Trip Amplifier Module
for Combustible Gas Applications



The information and technical data disclosed in this document may be used and disseminated only for the purposes and to the extent specifically authorized in writing by General Monitors.

INSTRUCTION MANUAL 01/96

General Monitors reserves the right to change published specifications and designs without prior notice.

Part No.
Revision

MANTA102A
E/01-96



E/01-96

Warranty Statement

General Monitors warrants the *Model TA102A* to be free from defects in workmanship or material under normal use and service within two (2) years from the date of shipment. General Monitors will repair or replace without charge any such equipment found to be defective during the warranty period. Full determination of the nature of, and responsibility for, defective or damaged equipment will be made by General Monitors' personnel. Defective or damaged equipment must be shipped prepaid to General Monitors' plant or the representative from which shipment was made. In all cases this warranty is limited to the cost of the equipment supplied by General Monitors. The customer will assume all liability for the misuse of this equipment by its employees or other personnel. All warranties are contingent upon proper use in the application for which the product was intended and do not cover products which have been modified or repaired without General Monitors' approval or which have been subjected to neglect, accident, improper installation or application, or on which the original identification marks have been removed or altered. Except for the express warranty stated above, General Monitors disclaims all warranties with regard to the products sold, including all implied warranties of merchantability and fitness and the express warranties stated herein are in lieu of all obligations or liabilities on the part of General Monitors for damages including, but not limited to, consequential damages arising out of/or in connection with the use or performance of the product.

Warnings

- COMBUSTIBLE & FLAMMABLE GASES AND VAPORS ARE VERY DANGEROUS. EXTREME CAUTION SHOULD BE USED WHEN COMBUSTIBLE & FLAMMABLE GASES AND VAPORS ARE PRESENT.
- All Zero Two Series Modules contain components which can be damaged by static electricity. Special care must be taken when wiring the system to ensure that only the connection points are touched.
- Smart Sensors and Point IR Detectors designed by General Monitors will work with the Model TA102A. Any attempt to use a Field Device that has not been designed and approved by General Monitors will void the warranty.
- **SAFETY WARNING:** **Installation and Maintenance must be carried out by suitably skilled and competent personnel only.**
- Full backwards compatibility can be specified at the time of order. If this configuration is specified, the rear terminal output designation will be identical to the previous generation of Zero Two Series Modules.
- This generation of product can be distinguished from the previous generation by the lack of a door on the front panel. Adjustments are not necessary on the current generation of this product.



	Page Number
Warranty	i
Warnings	i
Illustrations	iii
1 Introduction	
1.1 General Description	1
1.2 Features & Benefits	1
1.3 Applications	2
2 Specifications	
2.1 System Specifications	3
2.2 Mechanical Specifications	3
2.3 Electrical Specifications	3
2.4 Environmental Specifications	4
2.5 Engineering Specifications	4
3 Installation	
3.1 Upon Receipt of Equipment	7
3.2 Control Module Installation	7
3.3 Rear Terminal Connections	7
3.4 Sensor Location Considerations	12
3.5 Sensor Poisons	12
3.6 Applying Power	12
4 Operation	
4.1 General Maintenance	13
4.2 Electrical Inputs	13
4.3 Electrical Outputs	13
4.4 Accepting Alarm Conditions	14
4.5 Resetting Latched Alarm	15
4.6 CAL Open Collector	15
4.7 Card Test Feature	15
4.8 Test Gas & Calibration Mode	15
4.9 Fault Diagnostics	16
5 User Interfaces	
5.1 Types of User Interfaces	17
5.2 Setup Check & Setup Modes	17
5.3 Inhibit Mode Description	24
6 Sensor Assembly/Accessories	
6.1 Smart Sensors	25
6.2 Point IR Gas Detector	26
6.3 Splash Guard	26
6.4 Dust Guard Assembly	27
6.5 Duct Mounting Plates	27
6.6 Flow Block (IR2000)	28
6.7 Calibration Equipment	28



	<u>Number</u>
7 Appendix	
A Glossary of Terms	31
B Volatile Liquids and Solvents	33
C Engineering & Technical Drawings	34
D Ordering Information	42
E Zero Two Series Modules	43
8 Index	45

Illustrations

Figure 1	Isometric View of the Model TA102A.....	1
Figure 2	Control Module Coding Strip	7
Figure 3	Wire Strip Length.....	8
Figure 4	Rear Terminal Designations	8
Figure 5	Relay Protection Circuit for AC Loads	9
Figure 6	Relay Protection Circuit for DC Loads.....	10
Figure 7	Sensor / Controller Connections	10
Figure 8	Typical External Circuits for Open Collectors	11
Figure 9	Card Test Switch Wiring	11
Figure 10	Analog Signal Connections.....	11
Figure 11	Power Connections - Rear Chassis	11
Figure 12	Front Panel Display.....	17
Figure 13	Entering the Setup & Setup Check Modes	17
Figure 14	Entering the Password	17
Figure 15	Entering the Inhibit Mode	19
Figure 16	A2 Energized/De-Energized Alarm Option	19
Figure 17	A2 Latching/Non-Latching Alarm Option	19
Figure 18	A2 Alarm Set Point Option	20
Figure 19	A1 Energized/De-Energized Alarm Option	20
Figure 20	A1 Latching/Non-Latching Alarm Option	20
Figure 21	A1 Alarm Set Point Option	21
Figure 22	Fault / Inhibit Option	21
Figure 23	Entering Card Test Options	21
Figure 24	Card Test Ramp Time, 3 / 10 seconds	22
Figure 25	Alarm Output Option during a Card Test, Ac / nA	22
Figure 26	Password Enabled/Disabled Option	22
Figure 27	Entering a new Password	23
Figure 28	Models S104/S106, Picture	25
Figure 29	Block Diagram of Smart Sensor Control Functions	26
Figure 30	Model IR2000, Picture	26
Figure 31	Block Diagram of IR2000 Control Functions	26
Figure 32	Splash Guard, Picture	26
Figure 33	Dust Guard, Picture	27
Figure 34	Dust Guard Assembly Kit, Picture	27
Figure 35	Duct Mounting Plate, Assembly (Smart Sensors)	27
Figure 36	Duct Mounting Plate, Assembly (IR2000)	28
Figure 37	Flow Block, IR2000	28
Figure 38	Portable Purge Calibrator	28
Figure 39	3 Liter Calibration Chamber, Picture	29
Figure 40	Gas Application Assembly, IR2000	30
Figure 41	Schematic Diagram - Control Board	34 & 35
Figure 42	Schematic Diagram - Input Circuit	36
Figure 43	Schematic Diagram - Display Board	37
Figure 44	Circuit Card Assembly - Control Board	38
Figure 45	Circuit Card Assembly - Display Board	39
Figure 46	Outline & Terminal Connections	40
Figure 47	Final Assembly Drawing	41



This chapter provides a brief description of the Model TA102A, its features & benefits and a list of some of its applications. More detailed information on the features and benefits listed in section 1.2 will be presented in later chapters.

1.1 General Description

The General Monitors Model TA102A (see figure 1) is a single channel Combustible Gas Trip Amplifier designed for use in Zero Two Series Gas and Flame Detection Systems. This Module connects to the wires from a field mounted General Monitors Smart Sensor or Point IR Detector, which monitors combustible gases and vapors.

The Model TA102A is electrically and physically compatible with the other gas detection, flame detection and system modules in the Zero Two Series. It is distinguished from the other modules by its blue border and "TA102A" in the upper right corner of the front panel. The Model TA102A is designed for use in non-hazardous environments.




Figure 1

1.2 Features & Benefits

Microprocessor Based Electronics: monitors fault conditions, sensor inputs and provides outputs in the form of display codes, analog signal, relay contact and open collector activations.

Setup Mode: allows the user to set parameters such as alarm output options, test options, etc. These parameters are viewed on the display during the Setup Mode.

Password Option: prevents unauthorized alteration of the setup parameters (can be disabled).

Setup Check Mode: allows the user to view the parameters that have been set by the factory and/or an operator.

LED Test: tests the integrity of each display LED and each segment of the digital display on the front panel.

Card Test: tests the functionality of the card through the microprocessor ramping up the signal from 0 to full scale.

Live Insertion/Removal: allows the user to insert or remove a module while power is applied to the system without damage to any of the components in the system.



E/01-96

1.3 Applications

The General Monitors Model TA102A is a Trip Amplifier designed for Zero Two Series Combustible Gas Applications. Below is a partial list of applications:

- Refineries
- Drilling platforms and rigs
- Gas and oil production platforms
- Gas collection facilities
- Oil well logging operations
- LPG/LNG processing and storage
- Gas Turbines
- Solvent Vapors
- Hydrogen Storage
- Wastewater treatment plants
- Chemical plants



This chapter provides detailed specifications for the Model TA102A Zero Two Series Trip Amplifier Module. System, mechanical, electrical and environmental specifications present the Model TA102A in technical terms. The engineering specification provides a written specification that can be inserted into another written specification by architects and engineers:

2.1 System Specifications

Application: Combustible & Flammable Gas and Vapor Detection.

Sensor Type: General Monitors' Combustible Gas Smart Sensors or General Monitors' Point IR Hydrocarbon Detector.

Typical Sensor Life: 3 to 6 years in normal service for General Monitors' catalytic bead sensor (smart sensor element).

Measuring Range: 0 to 100% LEL/LFL.

Performance Accuracy: $\pm 3\%$ LEL/LFL or 10% of the applied gas, whichever is greater, at reference ambient conditions up to 50% LEL/LFL. $\pm 5\%$ LEL/LFL at reference ambient conditions above 50% LEL/LFL, up to full scale.

Display Accuracy: $\pm 1\%$ of full scale.

Zero Drift: Less than 5% of span per year.

Stability: Adheres to FMRC Class 6310 & Class 6320 and CSA 22.2 No. 152-M1984.

Response Time: $T_{50} \leq 10$ seconds with 100% LEL/LFL concentration of Methane (CH_4) applied. $T_{90} \leq 30$ seconds with 100% LEL/LFL concentration of Methane (CH_4) applied.

User Protection: CSA certified to CSA 22.2 No. 152-M1984 performance standard for combustible gas detection instrumentation.

Warranty: Two years

2.2 Mechanical Specifications

Weight: 11.2 oz. (318 grams)

Length: 9.9 inches (251 mm)

Height: 6.825 inches (173 mm)

Width: 1.0 inches (25 mm)

2.3 Electrical Specifications

Input Power Requirement: 20 to 35Vdc @ 375mA max. (24Vdc, 9W nominal with field device).

Electrical Classification: General Monitors' Smart Sensors and Point IR Detectors are rated for use in Class I, Division 1, Groups B, C & D. The Model TA102A is designed for use in non-hazardous environments.

Relay Contact Rating: 4A @ 250Vac, 3A @ 30Vdc resistive max. DPDT for A1 & A2, SPDT for Fault.

Open Collector Rating: 100mA @ 35 Vdc for A1, A2, Fault, UA, FUA, CAL-OC, LA1 & LA2.



E/01-96

Cable Parameters (continued)

Cable Parameters: Recommended 3 wire shielded, maximum cable lengths allowable between module and the Field Device with 24Vdc nominal at the sensor/detector:

AWG	Feet	mm ²	Meters
14	4500	2.5	1372
16	2250	1.5	685
18	1600	1.0	488
20	1100	0.75	335
22	750	0.25	228

The maximum allowable cable lengths between the analog output connections on the control module with a remote device in series (maximum loop resistance of 300 Ohms between Analog Signal & Common at the field device):

AWG	Feet	mm ²	Meters
14	9000	2.5	2740
16	5200	1.5	1585
18	3800	1.0	1160
20	2400	0.75	730
22	1600	0.25	488

2.4 Environmental Specifications

Operating Temperature Range:

Field -40°F to +140°F
 Device -40°C to +60°C

TA102A 0°F to +150°F
 -18°C to +66°C

Storage Temperature Range:

Field -40°F to +167°F
 Device -40°C to +70°C

TA102A -40°F to +150°F
 -40°C to +66°C

Operating Humidity Range:

5% to 100% Relative Humidity,
 non-condensing

2.5 Engineering Specifications

Zero Two System - Each system shall utilize modules capable of monitoring gas sensing elements or a 0 to 21.7mA analog signal from gas or flame detection transmitters. The system chassis shall be available in 4, 8 and 16 channels. Each chassis shall contain a bus for the following independent signals: A1 Alarm, A2 Alarm, Fault, Master Reset, Master Accept, Unaccept, CAL, +24Vdc and System Common. Module signals shall be capable of being bussed from one chassis to another, so that up to 100 modules can comprise a single system. The gas and flame detection modules shall be electrically and physically compatible and capable of being used in the same chassis to form combined fire and gas detection systems. The system shall consist of Zero Two Series component modules as manufactured by General Monitors, Lake Forest, California, U.S.A. or General Monitors, Galway, Ireland.



Engineering Specifications (continued)

TA102A Trip Amplifier Module - The trip amplifier module, with a General Monitors' sensor/detector, shall meet the performance requirements of CSA 22.2 No. 152-M1984 and be capable of monitoring 0 to 100% LEL/LFL concentration of combustible gases/vapors. The trip amplifier module shall have an interface panel, providing a mode/select switch and the following indications: 2 discrete alarm threshold level indicators, a fault or malfunction indicator, a ready indicator, a calibration mode indicator, a setup mode indicator and a 2 digit digital display. All alarm parameters and user options shall be software selectable. A power on self test (POST) shall automatically be performed each time the trip amplifier module powers up. A functional card test and a front panel LED test shall be switch capable without interrupting normal on-line services. The trip amplifier module shall be capable of insertion and removal during power on conditions without damage to any component module in the system. The trip amplifier module will generate display codes associated with fault conditions whenever a fault or malfunction occurs. A mode/select switch shall provide the operator front panel access to a setup check mode, a setup mode and an inhibit mode. The trip amplifier module shall have a password protected setup routine capable of having the password disabled.



This chapter discusses what to do when a Model TA102A is received, the terminal connections & designations, field device location considerations and what to be aware of when applying power.

3.1 Upon Receipt of Equipment

All equipment shipped by General Monitors is packaged in shock absorbing containers which provide considerable protection against physical damage. The contents should be carefully removed and checked against the packing slip. If any damage has occurred or if there is any discrepancy in the order, notify General Monitors as soon as possible. All subsequent correspondence with General Monitors must specify the equipment part and serial numbers.

Each Model TA102A is completely checked at the factory, however, a complete check-out is necessary upon initial installation and start up to ensure system integrity.

3.2 Control Module Installation

A rack or panel mounted chassis will be required when installing any Zero Two Series Module. These chassis should be mounted in non-hazardous, weather protected locations and should be subjected to minimal shock and vibrations. The rack and panel mounted chassis are available in 4, 8, and 16 channel sizes. Multiple 16 channel chassis may be connected to each other to form larger systems.

In installations where two or more module types are to be mixed in the same chassis, ensure that the individual coding strips match the channel application. The coding

strips are pre-configured at the factory and the male portion is already on each module. The female portion, if unmounted, must be fastened into position on the mounting strip of the desired chassis channel so as to mate with its counterpart on the module (see figure 2 below).




Figure 2

Zero Two series modules require air circulation to avoid excessive heat build-up. If chassis are stacked vertically within an enclosure, forced air circulation may be required. The Trip Amplifier Modules are, to a great extent, immune to electromagnetic interference (EMI). However, they should not be mounted in close proximity to radio transmitters or similar equipment.

3.3 Rear Terminal Connections

All wire connections to the Model TA102A are made to the terminal block located at the rear of the chassis. The terminal block accepts 16 AWG to 20 AWG, stranded or solid core wire.



E/01-96

Rear Terminal Connections (continued)

14 AWG wire may be used if it is properly stripped according to figure 3.



Strip Length

Figure 3

Contact with PC Board components should be avoided in order to prevent damage by static electricity.

To connect wires to the terminal block on the Model TA102A, loosen the desired screw, insert the stripped end of the wire and tighten.

For the rear terminal designations refer to figure 4 below:




Figure 4

A2 Alarm

The terminal designations for the A2 alarm outputs are:

Label	Term	Description
A2-C1	2d	Relay Common (1 & 2)
A2-1	4d	Relay Contact
A2-2	6d	Relay Contact
A2-3	8d	Relay Contact
A2-4	10d	Relay Contact
A2-C2	12d	Relay Common (3 & 4)
A2-OC	14d	Open Collector (OC)
LA2	24z	OC Logic for A2 LED

The A2 alarm outputs are DPDT relays, 1 open collector output (A2-OC) that follows the logic of the relays and 1 open collector output (LA2) that follows the blinking pattern of the front panel LED. The A2-C1 designation is common for A2-1 & A2-2. The A2-C2 designation is common for A2-3 & A2-4. The normally open (NO) and normally closed (NC) contacts depend on a user selectable option (see chapter 5).

The table below refers to the proper open and closed A2 alarm relay contacts while the unit is on power:

User Selected Relay State	Normally Open	Normally Closed
Normally Energized	A2-C1 & A2-1, A2-C2 & A2-4	A2-C1 & A2-2, A2-C2 & A2-3
Normally De-Energized	A2-C1 & A2-2, A2-C2 & A2-3	A2-C1 & A2-1, A2-C2 & A2-4



Rear Terminal Connections *(continued)*

A1 Alarm

The terminal designations for the A1 Alarm outputs are:

Label	Term	Description
A1-C1	2z	Relay Common (1 & 2)
A1-1	4z	Relay Contact
A1-2	6z	Relay Contact
A1-3	8z	Relay Contact
A1-4	10z	Relay Contact
A1-C2	12z	Relay Common (3 & 4)
A1-OC	14z	Open Collector (OC)
LA1	24d	OC Logic for A1 LED

The A1 Alarm outputs are DPDT relays, 1 open collector output (A1-OC) that follows the logic of the relays and 1 open collector output (LA1) that follows the blinking pattern of the front panel LED. The A1-C1 designation is common for A1-1 & A1-2. The A1-C2 designation is common for A1-3 & A1-4. The normally open (NO) and normally closed (NC) contacts depend on a user selectable option (see chapter 5).

The table below refers to the proper open and closed A1 alarm relay contacts while the unit is on power:

User Selected Relay State	Normally Open	Normally Closed
Normally Energized	A1-C1 & A1-1, A1-C2 & A1-4	A1-C1 & A1-2, A1-C2 & A1-3
Normally De-Energized	A1-C1 & A1-2, A1-C2 & A1-3	A1-C1 & A1-1, A1-C2 & A1-4

Fault Alarm

The terminal designations for the Fault outputs are:

Label	Term	Description
F-C	16z	Relay Common
F-1	18z	Relay Contact (NO)
F-2	20z	Relay Contact (NC)
F-OC	22z	Open Collector (OC)
FUA	32d	Open Collector (OC)

The Fault outputs are SPDT relays, 1 open collector output (F-OC) that follows the logic of the relays and 1 open collector output (FUA) dedicated to new fault indications. If the Backwards Compatible configuration is ordered, the FUA will not be present (pin 32d will be for the +24Vdc). The Fault outputs are always normally energized when power is applied to the module.

The contact ratings for the A2 & A1 alarm and Fault relays are 4A @ 250 Vac, 3A @ 30 Vdc, *Resistive, maximum*.

Inductive loads (bells, buzzers, relays, etc.) on dry relay contacts must be clamped down. Unclamped inductive loads can generate voltage spikes in excess of 1000 volts. Spikes of this magnitude may cause false alarms and contact damage. Figures 5 & 6 show recommended relay protection circuits for AC and DC loads, respectively.




Figure 5



E/01-96

Rear Terminal Connections (continued)




Figure 6

The terminal designation for the Unaccept output is:

Label	Term	Description
UA	18d	Open Collector Output

The terminal designations for the Discrete Calibration Output is:

Label	Term	Description
CAL-OC	32z	Open Collector Output




If the Backwards Compatible configuration is ordered, the CAL-OC will not be present (pin 32z will be for the COM).

The terminal designations for the Field Device connections are:

Label	Term	Description
WHT	26d,z	Signal IN (Analog)
RED	28d,z	VDC Out (+24Vdc)
BLK	30d,z	DC Common

Only one Field Device may be connected to a Model TA102A.

Figure 7 illustrates the inter-connections for the Trip Amplifier & the Field Device.





Rear Terminal Connections (continued)

The electrical rating for all open collector outputs is 100mA @ 35 Vdc.

Figure 8 illustrates some typical open collector external circuits.




Figure 8

The terminal designation for the Card Test Input is:

Label	Term	Description
CT	16d	Switch Connection

The Card Test Input is provided so that the user can access the Card Test feature remotely. One end of a normally open SPST switch is connected to this termination and the other end is connected to system common. To activate the feature, simply press and hold the switch for as long as the test time is to be run (minimum runtime is 3 or 10 seconds, software selectable). Figure 9 is a block diagram that shows the switch connections for the Card Test feature.





Figure 9

The terminal designations for the Analog Output Signal are:

Label	Term	Description
AO+	20d	Analog Signal (plus)
AO-	22d	Analog Signal (minus)

If the Analog Signal is not used a jumper must be placed between 20d & 22d.

Figure 10 is a diagram of the Analog Signal connections.



The maximum load resistance between AD+ & AD- cannot exceed 300 ohms.

Figure 10

Figure 11 indicates where the power connections for the chassis are made.




Figure 11



E/01-96

3.4 Sensor Location Considerations

There are no standard rules for sensor placement since the optimum sensor location is different for each application. The customer must evaluate conditions at the sensor site in order to make this determination.

Generally:

- The sensor should be easily accessible for calibration checks. Ensure that sufficient clearance exists to allow the use of field calibration devices such as the Remote Calibrator (Model RC-3) or a Portable Purge Calibrator for combustible gas applications.
- The sensor head should always be pointing down to prevent water build up on the sensing element. Remember that some combustible gases are heavier than air, however, do not rely too heavily on this fact when selecting a sensor position.
- The sensor should be located in areas where leaks are suspected (i.e. near valves & pipe connections, etc.).
- The sensor should not be placed where it may be coated by contaminating substances.

3.5 Sensor Poisons

Sensors may be adversely affected by prolonged exposure to certain atmospheres.

The more important poisons are:

- Prolonged exposure to Hydrogen Sulfide (H₂S) Gas
- Halides . . . compounds containing Fluorine, Chlorine, Bromine and Iodine
- Heavy Metals (e.g. Tetraethyl lead)

Silicones contained in greases or aerosols are the most common "coating" agents, which are not true sensor poisons, but reduce sensor response. Other damaging materials which attack the sensor physically include mineral acids and caustic vapors.

The presence of such poisons and vapors does not exclude the use of General Monitors Catalytic Bead Sensors, however, a careful analysis of ambient conditions should be undertaken and the customer should be aware that sensor calibration may need to occur at more frequent intervals.

3.6 Applying Power

Zero Two Series Modules do not have an ON/OFF power switch. Each module in the Zero Two Series operates from 24 Vdc. Power requirements will vary according to the number and type of modules in the system, as well as the number and type of field devices.



This chapter discusses what general maintenance to perform, describes the electrical inputs, outputs, accepting & resetting alarm, calibration & fault conditions and fault diagnostics.

4.1 General Maintenance

Once the Model TA102A has been installed, very little maintenance is required other than periodic checks to verify the integrity of the system.

- The user should evaluate conditions at the sensor site to determine how frequent calibration checks should be performed.
- A functional test of the system should be performed at least once each year. This test should include full operation of stand-by systems or back up power for the prescribed period.
- The power, sensor and output wiring should be checked for tightness, verifying that all of the components and devices are connected correctly.
- If the "Password" is disabled, periodic checks of the setup parameters should be performed.

4.2 Electrical Inputs

There are two electrical inputs to the Model TA102A. They are the General Monitors' Field Device and the Card Test input. Both of these input connections (field device and card test) are made to the rear terminal block (see chapter 3 for more detailed installation information).

- The Smart Sensor or Point IR Detector input consists of the standard three lead connections used with General Monitors' Field Devices (Black = Common, White = Signal, Red = +24Vdc). See figure 8 on page 10 of this manual.

- The Card Test input consists of a single termination for remote testing of the Model TA102A's functions. For detailed information on the Card Test, refer to figure 9 on page 11 of this manual.

4.3 Electrical Outputs

The electrical outputs on the Model TA102A consist of relay contacts, open collectors and an analog current signal.

- The following outputs have rear terminal relay contacts:
 - A1 Alarm - DPDT relay contacts
 - A2 Alarm - DPDT relay contacts
 - Fault - SPDT relay contacts

All of the relay contacts on the Model TA102A have a maximum rating of:

4A @ 250Vac, 3A @ 30Vdc resistive

- The following outputs have rear terminal open collectors:
 - A1 Alarm & LED Mimic
 - A2 Alarm & LED Mimic
 - Fault
 - UA - Unaccepted Alarm
 - FUA - Unaccepted Fault
 - CAL - Calib. & Calib. Check Modes

All of the open collector outputs on the Model TA102A have a maximum rating of:

100mA @ 35Vdc



E/01-96

Electrical Outputs *(continued)*

- The Analog Output Signal is used for sending gas concentrations and status information to remote devices. The maximum analog load may not exceed 300 ohms from the Field Device to the Trip Amplifier to any other remote device and back to the Field Device, including the wire/cable. The rear termination labeled "Signal IN" is part of the overall analog loop. The analog signal is generated by the field device and passes through the Model TA102A. This signal is a 0 to 21.7mA current signal with 4 to 20mA being proportional to 0 to 100% of full scale. When the field device is placed in the calibration or calibration check mode a 1.5mA signal (0mA is optional for the field device) is generated by this output. During the calibration or calibration check mode the display on the TA102A will indicate **CA** if the CAL current is 1.5mA. If the CAL current is 0mA the display will indicate **F4** (field device error).

When the Model TA102A enters into a fault condition the Analog Output Signal is pulled down to 0mA. During a fault the display will indicate a fault code ("F" followed by a digit).

If the sensor attached to the Model TA102A is seeing gas in excess of 100% of full scale, this output will generate a signal between 20 and 21.7mA (not proportional). An over range condition is indicated by a flashing digital display reading full scale (**99**).

4.4 Accepting Alarm Conditions

Whenever a new alarm condition occurs the front panel LED and open collector associated with that alarm (LA1 or LA2) will flash. In addition, the associated alarm

outputs and the unaccept outputs (TA102A, UA open collector & FM002A, UA relay) will activate, unless they are already activated. The flashing front panel alarm LED and rear terminal open collector indicate that a new alarm has been activated. New alarms should be acknowledged or accepted. This is accomplished with the Master Accept Button located on the Facilities Module. Pressing the Master Accept Button de-activates the UA outputs and causes the associated front panel alarm LED and rear terminal open collector to stop flashing and energize.

NOTE: Alarms that latch must be Accepted before they can be Reset (see 4.5 of this chapter).

There is a unique situation that may occur with some frequency in certain applications. An alarm may occur and the operator will accept this alarm by pressing the Master Accept Button. If the alarm output is latching and the condition at the sensor returns to normal (safe) the alarm output will need to be reset. If, however, the alarm output is accepted but not reset and that alarm set point is exceeded again, the front panel LED, the associated mimic open collector and the unaccept outputs will reflash or re-activate. This gives the operator an indication of a new alarm condition that must be re-accepted.

A type of alarm, other than the A1 & A2 alarms, is the fault alarm. The fault alarm can be accepted similarly with the A1 & A2 alarms. The front panel fault LED will flash and the fault unaccept (FUA) open collector will energize when a fault is detected. If the operator presses the accept button, the FUA output will de-energize and the Fault LED will stop flashing, but stay illuminated until the fault condition is corrected.



4.5 Resetting Latched Alarms

The user may select a "latching" or "non-latching" alarm output for A1 and/or A2. If an alarm output activates and the condition that caused that activation is no longer present, a non-latching alarm output will reset automatically, whereas a latched alarm output will need to be reset manually. Resetting latched alarm outputs is accomplished with the Master Reset Button located on the Facilities Module (FM002A). Pressing the Master Reset Button will reset any latched conditions that are no longer valid.

NOTE: Latched alarm conditions cannot be Reset until they have been Accepted (see section 4.4 of this chapter).

Whenever the Model TA102A receives a 20mA signal, or higher, the front panel alarm LEDs, the digital display and rear terminal alarm outputs will latch until the input signal drops below the alarm set points and the Reset Button is pressed (twice if A1 or A2 have latching outputs). This lets the operator know that a combustible level was present at the field device.

The Master Reset Button performs another function. If the operator presses and holds the Master Reset Button for two or more seconds, all of the LEDs and LED segments in the digital display will illuminate for as long as the operator presses the button. This is called the LED Test. The LED test cannot be performed while the unit is in alarm or fault or during a Card Test.

4.6 CAL Open Collector

There is an open collector that will energize anytime the Field Device is placed in the Calibration Mode or the Calibration Check Mode. This open collector output is referenced to the system's ground/common. Energizing this output merely provides a

path to ground as is the case with all energized open collector outputs. De-energized, this output will be in a high impedance state.

4.7 Card Test Feature

The Card Test Input is provided so that the user can access the Card Test feature remotely. One end of a normally open SPST switch is connected to this termination and the other end is connected to system common (see figure 9 on page 11).

To activate the Card Test feature, simply press and hold the switch for at least three seconds. The front panel LEDs and digital display will begin ramping up at the start of the card test and will continue to ramp up for the software selectable ramp time specified by the operator (3 or 10 seconds) during the Setup Mode (see section 5.4). Each alarm level (A1 & A2) will trip when the alarm setpoint is exceeded. The analog output signal will ramp from 4 to 20mA during the test. At the conclusion of the Card Test, the A1 & A2 outputs will automatically reset (overriding any latching option). A Card Test cannot be initiated if the unit is in alarm or fault or during an LED Test.

NOTE: The relays (A1 & A2) and open collector outputs are active and will trip during the Card Test, unless the user specified option disabling these outputs is selected during the Setup Mode. This should be treated as a functional test of a Zero Two System.

4.8 Test Gas & Calibration Mode

In order to ensure the integrity of life protecting equipment General Monitors' recommends that field devices have periodic calibration checks to determine if a calibration is necessary.



E/01-96

Test Gas & Calibration Mode *(continued)*

General Monitors' Combustible Gas Smart Sensors are equipped with a Calibration Check Mode to perform a calibration check.

The Model IR2000 does not require field calibration, however, the unit does include a test gas mode that allows the operator to apply a known gas concentration and verify the reading on the IR2000 display. During this "Test Gas" mode, the IR2000 will output a 1.5mA or a 0.0mA signal to the TA102A. The 1.5mA signal is the standard Test Gas output signal and will cause the **CAL** LED to illuminate and the display to indicate **CA** on the Model TA102A. The 0.0mA signal is an optional Test Gas output signal that activates the Fault outputs, causes the **FAULT** LED to illuminate and displays **F4** on the Model TA102A.

Similarly, the Combustible Gas Smart Sensors include a Calibration Check (Test Gas Mode) mode with a standard 1.5mA or an optional 0.0mA calibration output signal. These Smart Sensors may require periodic calibration of the sensing elements. Refer to the specific instruction manual for detail information on calibrating the field device (*S104 & S106*).

When the Model TA102A receives a 1.5mA signal from the field device, the CAL LED, the CAL-OC output and the CALBUSS are activated.

4.9 Fault Diagnostics

In addition to the Fault LED on the front panel, the Model TA102A provides a fault code on the digital display whenever a fault condition occurs. The Fault Codes that can appear on the digital display are summarized in the next column.

- **F1, F2, F5 & F9** - Are not used at this time. These codes have been reserved for future use.
- **F3** - Program checksum error. This fault occurs during initial power-up of the unit. If this fault occurs, remove and reapply power to the unit. If the fault continues to occur, replace the unit and consult your GMI Representative or the factory.
- **F4** - Field device error. Make sure the wires running to and from the Trip Amplifier and the Field Device are connected properly. Check for opens and shorts across the field wiring. Make sure the analog signal is returned to the field device or common (jumper AO+ & AO- if unused). Possibly an optional 0mA Calibration Current from the Smart Sensor.
- **F6** - Low supply voltage. Make sure the supply voltage level at the chassis is 24Vdc.
- **F7** - EEPROM verification failure. This fault will occur if the microprocessor can not store calibration or setup information in the EEPROM. If this fault occurs consult the factory or your GMI Representative.
- **F8** - Failed to complete setup. This fault may occur during or immediately after the Setup Mode. If this fault occurs consult the factory or your GMI Representative.


In each of the fault cases listed on this page, when the fault occurs the FUA output is activated. Pressing the **ACCEPT** button on the Facilities Module (FM002A) will acknowledge the fault, de-activate the FUA output and the fault LED will stop flashing and remain **ON** until the fault is corrected.



This chapter discusses the user interfaces, the Setup Check & Setup Modes and the Inhibit Mode.

5.1 Types of User Interfaces

User interfaces are provided so that the operator may interpret and direct the Model TA102A in the performance of its various functions. User interfaces (figure 12) consist of a digital display, status indicators and a Mode/Select switch.



The digital display provides the user with the gas concentration at the sensor site, fault diagnostic codes and setup parameters. The status indicators provide the user with an indication of the current mode of operation (alarm, fault, ready, calibration and setup). The Mode/Select switch provides the user access to the Setup Check, Setup and Inhibit modes.

Figure 12

5.2 Setup Check & Setup Modes

The Setup Check Mode allows the operator to view the selected options for the module without allowing any changes to be made. Once this mode has been entered, the module will automatically display each of the selected options for a short period of time. The Setup Mode allows the operator to change the operating parameters by making choices for selected options.

The Setup Check and Setup Modes display identical information with the following exceptions:

- The Setup Check Mode allows the user to view the operating parameters of the Model TA102A, whereas the Setup Mode allows the user to change these parameters.
- Entering the optional Password is only available in the Setup Mode.
- The Inhibit Mode may only be entered from the Setup Mode. If the Inhibit Mode is entered, the unit will remain in the Inhibit Mode until the Mode/Select switch is pressed.
- After the Setup Mode is complete the TA102A will execute the Setup Check Mode to view the selected parameters.

NOTE: *The Setup and Setup Check Modes cannot be entered if the unit is in alarm or fault. If the field device is in calibration, calibration check or test gas mode the Setup and Setup Check Mode cannot be entered.*

During the Setup Mode the operator will be allowed to select options. The selection procedure is the same for most of the options. Pressing the Mode/Select Switch toggles the available choices. When the display has indicated a choice for five consecutive seconds, without the operator pressing the Mode Select Switch, the Setup routine will accept that selection and move on to the next option available. These modes will activate the CAL LED, the CAL-OC output and the CALBUSS.

NOTE : *Before entering the Setup Mode to make changes, the user should become familiar with the block diagram on page 18 and fill out the form listed there. This will aid the user during the selection process in the Setup Mode.*



E/01-96

Setup Check & Setup Modes *(continued)*

This section is provided to aid the operator in making selections during the Setup Mode. It is recommended that the operator fill in the selections in the proper blanks and then use this page as a reference while programming the TA102A. The blocks shown below indicate the order of options in the Setup Mode. To the right of each block is a description of the choice(s) that are available. More information about making each selection is provided in the pages that follow.

Password	Enter the Password, if the Password is enabled.	
Inhibit Mode ?	Enter the Inhibit Mode, if desired.	<u>ENTER SELECTION</u>
A2 Alarm Options	Set the Energized (En) / De-Energized (dE) Option Set the Latching (LA) / Non-Latching (nL) Option Set the A2 alarm set point (from 5 to 60, in increments of 5)	_____ _____ _____
A1 Alarm Options	Set the Energized (En) / De-Energized (dE) Option Set the Latching (LA) / Non-Latching (nL) Option Set the A1 alarm set point (5 to the A2 set point)	_____ _____ _____
Fault/Inhibit Option	Set the Fault Activate (Ac) or not (nA) during inhibit Option	_____
Card Test Options	Display will indicate "ct" for 5 seconds Set the ramp time for the Card Test Mode (3 or 10 seconds) Set the Alarm outputs for Active (Ac) or Not Active (nA)	_____ _____
Password Options	Set the Password to be Disabled (Pd) or Enabled (PE) If the Password is Enabled: Set the password digits Left _____ Right _____	_____
Setup Check Mode	After all of the options have been selected, the TA102A will enter the Setup Check Mode.	



Setup Check & Setup Modes (continued)

NOTE: The Password, the A1 & A2 Alarm set points and the calibration level options offer the operator more than two choices. While these options are being selected, pressing the Mode/Select Switch will sequence the display to the next available choice for that option.

ENTERING THE SETUP MODE

To Enter the Setup Check Mode or the Setup Mode, press and hold the Mode/Select switch until the **SETUP** LED begins flashing (about ten seconds). When the **SETUP** LED is flashing, release the Mode/Select switch to enter the Setup Check Mode (figure 13). Continuing to press and hold the Mode/Select switch until the **SETUP** LED stops flashing (about fifteen seconds) will allow the operator to enter the Setup Mode. When the **SETUP** LED stops flashing and stays on, release the Mode/Select switch and the unit will enter the Setup Mode (figure 13).




Figure 13

ENTERING THE PASSWORD

- **This option applies to the Setup Mode only:** If the password option is enabled, the right digit of the display will be blank and a **0** will appear in the left digit on the display (figure 14). If the number is incorrect, press the Mode/Select switch until the correct number is displayed, then wait about five seconds.

The left digit of the display will be blank and a **0** will appear in the right digit on the display (figure 14). If the number is incorrect, press the Mode/Select switch until the correct number is displayed, then wait about five seconds. If the password is correct the user will proceed with the inhibit option. If the password is incorrect the user will not be able to proceed and unit will return to the normal operating mode. Once in the operating mode the user may attempt to re-enter the Setup Mode. The factory default password is **00**.




Figure 14



E/01-96

Setup Check & Setup Modes (continued)

ENTERING THE INHIBIT MODE

- This option applies to the Setup Mode only: If the password option is disabled, or after the correct password has been entered, the display will indicate **In** for five seconds (figure 15). Pressing the Mode/Select switch while **In** is displayed, will cause the unit to enter the Inhibit mode by inhibiting the alarm outputs. After the Model TA102A has entered the Inhibit mode, pressing the Mode/Select switch causes the unit to return to normal operation (see section 5.3). If it is desired to enter the Setup Mode, do not press the Mode/Select switch for the five seconds that **In** is displayed.




Figure 15

A2 ALARM OPTIONS

- After the Password and Inhibit mode options, the **A2** LED on the front panel will be flashing while the Energized/De-energized option is displayed (figure 16). The display will indicate the current selection, (**En** or **dE**). De-Energized is the factory default for this selection.




Figure 16

- The **A2** LED on the front panel will be flashing while the latching/non-latching option is displayed (figure 17). The display will indicate the current selection, (**nL** or **LA**). Latching is the factory default for this selection.




Figure 17



Setup Check & Setup Modes (continued)

- The last A2 alarm option to appear on the display will be the alarm set point (trip level). The A2 set point cannot be set lower than the current A1 set point. To accomplish this the operator must set the A1 set point lower than the desired A2 set point, then re-enter the Setup Mode and select the desired A2 set point.

If the set point is reached or exceeded the A2 alarm outputs will activate. The display will indicate the current A2 alarm set point (figure 18). Press the Mode/Select switch repeatedly, until the desired A2 alarm set point appears on the display. **60** is the factory default for this selection (max. setting per FMRC).




Figure 18

A1 ALARM OPTIONS

- Next, the **A1** LED on the front panel will be flashing while the Energized/De-energized option is displayed (figure 19).




Figure 19

The display will indicate the current selection, (**En** or **dE**). De-Energized is the factory default for this selection.

- The **A1** LED on the front panel will be flashing while the latching/non-latching option is displayed (figure 20). The display will indicate the current selection, (**nL** or **LA**). Non-Latching is the factory default for this selection.




Figure 20



E/01-96

Setup Check & Setup Modes (continued)

- The last A1 alarm option to appear on the display will be the alarm set point (trip level). If this level is reached or exceeded the A1 alarm outputs will activate. The display will indicate the current A1 alarm set point (figure 21). Press the Mode/Select switch repeatedly, until the desired A1 alarm set point appears on the display. 30 is the factory default for this selection.




Figure 21

FAULT / INHIBIT OPTION

- After the A1 alarm options have been selected, the user will select the Fault/Inhibit option. The **FAULT** LED on the front panel will be flashing while the display indicates **Ac** or **nA** (figure 22). An **Ac** selection specifies that the Model TA102A will activate the Fault circuit while the unit is in the Inhibit Mode. An **nA** selection specifies that the Model TA102A will not activate its Fault circuit when the unit is placed in the Inhibit Mode (see section 5.3). An **nA** selection will not disable the Fault circuit, therefore, if a Fault occurs during the Inhibit Mode, the unit will activate the Fault circuit. Not Active is the factory default for this selection.




Figure 22

CARD TEST OPTIONS

After the Fault/Inhibit option has been selected, the user will select the ramp time (3 or 10 seconds) and whether or not the alarm outputs will activate during a Card Test. The display will indicate **ct** for about five seconds (figure 23).




Figure 23



Setup Check & Setup Modes (continued)

- Following **ct**, the ramp up time (**3** or **10**) during the card test (figure 24) will be displayed. **3** is the factory default for this selection.




Figure 24

- Next, the display will indicate the alarm output option during a Card Test as either **Ac**, active or **nA**, not active. (figure 25). Not Active is the factory default for this selection.




Figure 25

NOTE: Selecting **nA** option for the Card Test will not inhibit the Fault or A1/A2 alarm circuits in the event of a malfunction or gas condition, during normal operation.

PASSWORD OPTION

- Once the Card Test options have been selected, the user will either enable or disable the password option (figure 35). The display will indicate either **PE**, for enabled or **Pd**, for disabled. Password Disabled is the factory default for this selection.




Figure 26



E/01-96

Setup Check & Setup Modes (continued)

ENTERING A NEW PASSWORD

This option applies to the Setup Mode only: If the Password is disabled, the unit will automatically enter the Setup Check mode. If the Password is enabled, the user will be able to enter a new password (refer to the NOTE on page 19). The unit will display the left digit of the Password on the display. The right digit will be blank until the left digit has been selected. Once the left digit is selected, wait for five seconds. Next, the right digit will be displayed and the left digit will be blank until the right digit has been selected. Once the right digit has been selected, wait for five seconds (figure 27).




Figure 27

When the Setup Mode is complete, the Model TA102A will automatically enter the Setup Check Mode. This allows the operator to view the newly selected options. The unit will return to normal operation after completing the Setup Mode and the Setup Check Mode.

5.3 Inhibit Mode Description

Whenever the Inhibit Mode is entered (see section 5.2), the A1 and A2 rear terminal alarm outputs are inhibited. The front panel A1 and A2 LEDs will still function normally, in cases where sufficient

combustible gas is present. If the password option is disabled, or after the correct password has been entered, the display will indicate **In** for five seconds (figure 15 on page 19). Pressing the Mode/Select switch while **In** is displayed, will cause the unit to enter the Inhibit mode by inhibiting the alarm outputs. After the Model TA102A has entered the Inhibit mode, pressing the Mode/Select switch causes the unit to return to normal operation. If it is desired to enter the Setup Mode, do not press the Mode/Select switch for the five seconds that **In** is displayed.

NOTE: Any latched alarms must be reset before exiting the Inhibit Mode.

There is a user selectable option that will place the unit in Fault every time the Inhibit Mode is entered. If the operator does not select this option the Fault circuits will function normally during the Inhibit Mode (i.e. they will not be inhibited).

While the unit is in the Inhibit mode, the display will indicate **In** for 5 seconds, then the Gas Concentration will be displayed for 5 seconds. This sequence will repeat for as long as the unit is in the Inhibit mode.

The Inhibit Mode is provided so that the operation of Model TA102A can be verified without tripping external devices that are connected to the A1 and A2 outputs. This type of verification usually occurs during "Initial Start-Up" and/or "Commissioning".

NOTE: The Calibration and Calibration Check Modes are accessed at the field device. Refer to the Instruction Manual of the specific field device for entering and using the Calibration and Calibration Check Modes (also see Sensor Assembly/Accessories Section of this Manual). The Calibration Check Mode is sometimes referred to as the Test Gas Mode.



This chapter provides a description of the types of field devices (Smart Sensors, Point IR Gas Detectors), and the accessories, that can be used with these field devices.

6.1 Smart Sensors

Generally speaking, General Monitors' field devices fall into two categories; Smart Sensors and Point IR Gas Detectors. Each type of Smart Sensor features a 4 to 20mA output that is proportional to the gas concentration at the sensor, microprocessor based electronics, automated calibration sequence, plus a digital display.

The Model S104 (figure 28) was designed to replace the SC100 (a previous model) and features enhanced electronics, housing improvements and greater fault diagnostics. A sister model, the S106A, has all of the features of the S104 plus 3 on board SPDT relays (2 alarm, 1 fault).




Figure 28

The detection elements for General Monitors Smart Sensors includes a variety of Catalytic Bead Sensors with different detection ranges, sensor bodies and flame arrestors:

- 10001-1* General Purpose, Aluminum Body, Wire Screen Arrestor
- 10014-1* High Temperature, Aluminum Body, Wire Screen Arrestor
- 10015-1 High Temperature, Aluminum Body, Sintered Flame Arrestor
- 10022-1 Industrial PTB, Aluminum Body, Sintered Flame Arrestor
- 10058-1* General Purpose, Stainless Steel Body, Wire Screen Arrestor
- 10059-1 Industrial PTB, Stainless Steel Body, Sintered Flame Arrestor
- 10084-1 High Temperature, Stainless Steel Body, Sintered Flame Arrestor
- 10164-1 Hydrogen Specific, Aluminum Body, Wire Screen Arrestor
- 10387-4 Super Poison Resistant, Alum., Body, Wire Screen Arrestor
- 10391-1 High Temp., Stainless Steel Body, Wire Screen Arrestor

* = Poison resistant sensors are available



E/01-96

Smart Sensors (continued)

The block diagram in figure 29 illustrates the Smart Sensor's control electronics. Only the Model S106A has relays, otherwise the functions shown in figure 29 are identical for each combustible gas smart sensor.




Figure 29

6.2 Point IR Gas Detector

General Monitors has developed an alternative field device for combustible gas applications. The Model IR2000 (figure 30) is a Point IR Hydrocarbon Gas Detector that uses IR absorption techniques to detect the presence of hydrocarbons.




Figure 30

The block diagram in figure 31 illustrates the IR2000's control electronics.




Figure 31

6.3 Splash Guard & TGA-1

General Monitors produces a universal Splash Guard, P/N 10395-1, that has been designed for use on all General Monitors combustible gas and hydrogen sulfide gas sensors (figure 32). In addition to the Splash Guard, a Test Gas Applicator (TGA-1) is available for delivering a test gas to remotely located sensors, P/N 10460-2.

The Splash Guard prevents water from rain or equipment wash downs from being forced into the sensor cavity and affecting the response of the sensing element. Constructed of rugged Valox plastic, it has a series of internal baffles to deflect water down and away from the sensor. This guard (and the TGA-1) are threaded for simple screw on installation. The splash guard and TGA-1 are recommended for outside applications where rain or frequent hose downs occur, such as offshore platforms.



Figure 32



6.4 Dust Guard Assembly

The Dust Guard Assembly (figure 33) is a simple, threaded stainless steel cylinder with a wire screen at one end. It is easily removed for cleaning and/or replacement of the disposable screen.

This General Monitors accessory is specifically designed to prevent dust and particulate matter from reaching the sensor flame arrestor. Such debris can plug the screen and limit the amount of gas reaching the active surface of the sensor.




Figure 33

The Dust Guard is also available in a kit with twelve replaceable screens (figure 34). It can also be used as an effective wind screen, and is recommended for corrosive, windy or high temperature environments.




Figure 34

6.5 Duct Mounting Plates

General Monitors produces a Duct Mounting Plate (P/N 10041) for applications that require the sensor to be mounted in an air-conditioning or heating duct. The Duct Mounting Plate is easy to install (figure 35).




Figure 35

Read and understand the bulleted list below before mounting the Sensor into a duct.

- Select a location on the duct and cut out a hole large enough for the Sensor to be inserted into the duct.
- Place the O-Ring over the Sensor threads, against the 1 & 1/4 inch hex on the wiring side of the sensor.
- Insert the wiring side of the Sensor through the Gasket and Cover.
- Screw the Lock-Nut onto the wiring side of Sensor.
- Use the four Screws to attach the mounted Sensor to the duct. The Sensor should be oriented so that when the plate is attached to the duct the sensing element is inside the duct.

The Duct Mounting Plate (P/N 10041) is designed for use with General Monitors Catalytic Bead and MOS Sensors. This product may not be used with the Model IR2000.



E/01-96

Duct Mounting Plates *(continued)*

The Model IR2000 uses the Duct Mounting Plate shown in figure 36 (P/N 30499-1).




Figure 36

6.6 Flow Block (IR2000)

General Monitors produces a Flow Block (P/N 30554-1) for applications that require the Model IR2000 to take a remote sample. To install the Flow Block, replace the gas detection cover on the IR2000 with the assembly shown in figure 37.




Figure 37

6.7 Calibration Equipment

General Monitors' Smart Sensors use the Portable Purge Calibrator (figure 38) or the 3 Liter Chamber (figure 39) to accomplish calibration.

Refer to the instruction manual of the Smart Sensor for the specific calibration procedure when using the Portable Purge Calibrator.




Figure 38

The following items are a list of Portable Purge calibration gases and part numbers:

Portable Purge Calibrator Assembly:

with 50% LEL Methane Gas	1400150-M
with 50% LEL Hydrogen Gas	1400150-H
with 50% LEL Ammonia Gas	1400150-A
with 50% LEL Butadiene Gas	1400150-BD
with 50% LEL Butane Gas	1400150-B
with 50% LEL Ethane Gas	1400150-E
with 50% LEL Ethylene Gas	1400150-EY
with 50% LEL Propane Gas	1400150-PR

Portable Purge Replacement Cylinder:

with 50% LEL Methane Gas	1400155-M
with 50% LEL Hydrogen Gas	1400155-H
with 50% LEL Ammonia Gas	1400155-A
with 50% LEL Butadiene Gas	1400155-BD
with 50% LEL Butane Gas	1400155-B
with 50% LEL Ethane Gas	1400155-E
with 50% LEL Ethylene Gas	1400155-EY
with 50% LEL Propane Gas	1400155-PR

Replacement Parts:

Small Calibration Cup	1400152-1
Large Calibration Cup	1400154
Pressure Gauge Regulator	922-009

Cylinder Refills:

50% LEL Methane Gas	140015-M
50% LEL Hydrogen Gas	140015-H

The 3 Liter Chamber is used when a Smart Sensor is calibrated with liquid or solvent vapors. Before the Smart Sensor is calibrated with any solvent or volatile liquid, consult the listing in Appendix B of this instruction manual to determine the volume



Calibration Equipment *(continued)*

of solvent/liquid required to produce a 50% LEL concentration in the 3 Liter Chamber. Before using the 3 Liter (3L) Chamber, make sure the following is present: 3 Liter Chamber, Dish, 250 microliter syringe, the correct volume of solvent/liquid for calibration/check.




Figure 39

- Orient the chamber so that the lid and sensor hole are on top.
- It will be necessary to wind up the fan using the turnkey on the outside of the chamber. If the fan begins to turn, locate the switch underneath and behind the fan blades on the inside of the chamber and turn the fan off.
- Insert the sensor into the sensor hole, open the lid and place the dish at the bottom of the chamber.
- Draw the correct amount of solvent/liquid into the syringe, according to the listing in Appendix B.
- Place the Smart Sensor in the Calibration Check or Calibration Mode, following the instructions listed in the Smart Sensor's instruction manual.

Cal Check Mode using the 3L Chamber:

- ① When **0** is flashing on the display (Calibration Check Mode) inject the solvent/liquid into the dish, reach underneath and behind the fan blades on the inside of the chamber, locate the fan switch; turn it on and close the lid on the 3 Liter Calibration Chamber.
- ② As the sensor begins to respond to the combustible vapor in the chamber, the concentration will begin flashing on the display of the Smart Sensor.
- ③ The reading will stabilize after one or two minutes.
- ④ Remove the sensor from the chamber and allow it to see clean air. When the display has stopped flashing and indicates a few % LEL and then zero (**0**), the Smart Sensor has returned to normal operation.

Cal Mode using the 3 L Chamber:

- ① When **AC** (Calibration Mode) appears on the display of the Smart Sensor, inject the solvent/liquid into the dish, reach underneath and behind the fan blades on the inside of the chamber, locate the fan switch; turn it on and close the lid on the 3 Liter Calibration Chamber.
- ② As the sensor begins to respond to the combustible vapor in the chamber, the display on the Smart Sensor will indicate **CP** (Calibration in Progress).
- ③ After one or two minutes the display will indicate **CC** (Calibration Complete).
- ④ Remove the sensor from the chamber and allow it to see clean air. When the display indicates a few % LEL and then zero (**0**), the Smart Sensor has returned to normal operation.



E/01-96

Calibration Equipment *(continued)*

- Remove the Dish from the 3 Liter Chamber and clean thoroughly before using it again.

The Model IR2000 does not require calibration, however a Test Gas Mode has been provided so that the operator can verify the integrity of the unit. In order to apply gas to the Model IR2000, General Monitors has developed a Gas Application Assembly (figure 41).




Figure 40



Glossary of Terms

AC - Alternating Current.

Analog - Continuous, without steps.

Ambient Temperature - Surrounding or background Temperature.

AWG - American Wire Gauge.

Calibration - Applying a known level of gas to a sensor and making adjustments so that the output signal matches the level of applied gas.

Canadian Standards Association - CSA is an approval agency. Testing laboratories will test Gas Detection Instruments to the standards set by approval agencies such as CSA. CSA certification is required for selling such equipment in Canada. CSA standards are recognized by many organizations outside of Canada.

Catalyst (Catalytic) - A substance that speeds up or slows down the rate of a chemical reaction. Any substance acting as the stimulus in bringing about or hastening a result.

Class I, Division 1 - This is a National Electric Code (NEC) classification dealing with hazardous locations and the degree with which the hazard is present. Class I, Division 1 is defined as any location where ignitable concentrations of flammable gases or vapors may be present under normal operating conditions. For more information on hazardous locations, refer to the NEC Handbook, Article 500.

COM - Common.

Conduit - Tubing, piping or a protected trough for electrical wires.

DC - Direct Current.

DCS - Distributed Controls System.

Digital - Stepped in specific increments.

Diffusion - A process by which molecules or other particles intermingle as a result of random thermal motion.

Drain Loop - The purpose of a drain loop is to collect condensation so as to prevent moisture from entering the housing.

EEPROM - Electrically Erasable Programmable Read Only Memory.

EMI - Electro-Magnetic Interference.

FMRC - Factory Mutual Research Corporation.

Group B - Atmospheres containing more than 30% Hydrogen or gases/vapors of equivalent hazard.

Group C - Atmospheres such as cyclopropane, ethyl ether, ethylene, or gases/vapors of equivalent hazard.

Group D - Atmospheres such as acetone, ammonia, benzene, butane, ethanol, gasoline, hexane, methanol, methane, natural gas, naphtha, propane, or gases/vapors of equivalent hazard.

Halogen Free Solvent - Solvent that does not contain any of the following: astatine, bromine, chlorine, flourine, or iodine.

Latching - Holding on to. Latching Alarms require manual resetting.

LEL/LFL - Lower Explosive Limit, Lower Flammable Limit. This is the minimum concentration necessary to support combustion.

mA - Milliampere, one thousandth (.001) of an amp.



E/01-96

Glossary of Terms *(continued)*

Microprocessor Base Electronics - All of the input signal processing, fault monitoring, calibrating routines, setup routines, and the outputs are under the control of a microprocessor unit (MPU).

mV - Millivolt, one thousandth of a volt.

PCB - Printed Circuit Board.

PLC - Programmable Logic Controller.

Potentiometer - An adjustable resistor.

RFI - Radio Frequency Interference.

T50 - This is the amount of time it takes the sensor to reach the 50% level of the applied gas.

TB - Terminal Block.



Volatile Liquids and Solvents

Volatile liquids and solvents are not supplied by General Monitors. This page provides a listing of volatile liquids and solvents and the respective volumes required (in microliters) to produce a 50% LEL vapor concentration in the 3 Liter Chamber (see section 6.7).

Reference : NFPA 325, 1994 Edition

Acetaldehyde	136	Isopentane	99
Acetic Acid	140	Isoprene	89
Acetone	112	Isopropyl Alcohol	93
Acetonitrile	96	Isopropyl Ether	120
Acrylonitrile	120	JP-4, Jet Fuel	183
Amyl Acetate	100	Laktane	76
Amylamine	156	Methanol	148
Benzene	65	Methyl Ethyl Ketone (MEK)	76
Butyl Acetate	137	Methyl Metacrylate	111
Butyl Acrylate	148	Naptha (Petroleum Ether)	96
Butyl Alcohol	78	Octane	99
sec-Butyl Alcohol	95	Pentane, Normal	105
tert-Butyl Alcohol	138	Propanal	114
Butyl Cellosolve	88	2-Propanol	93
Butyraldehyde	102	Propyl Acetate	106
Cyclohexane	86	Propylamine	103
Decane	95	Propylbenzene	68
Diethyl Ketone	103	Propylene Oxide	98
Diisobutyl Ketone	82	Styrene	63
Dimethylformamide	104	Tetradecane	79
p-Dioxane	104	Tetrahydrofuran	99
Dodecane	83	Tetrahydrofurfuryl Alcohol	89
Ethyl Alcohol (Ethanol)	118	Toluene	78
Ethyl Acetate	119	1,1,1-Trichlorethane	456
Ethyl Amine	140	Trichloroethylene	438
Ethyl Benzene	60	Triethylamine	102
Ethyl Ether	120	Vinyl Acetate	152
Ethylene Oxide	89	Vinyl Ethyl Ether	99
Gasoline 100 Octane	107	o-Xylene	67
Heptane, Normal	94	p-Xylene	83
Hexane, Normal	86	Xylenes	83

The volatile liquids and solvents listed in this section are intended for use in the 3 liter chamber for calibrating General Monitors Catalytic Sensors (not the Model IR2000).



E/01-96

Engineering & Technical Drawings

Reference Drawing # 11145-1

Schematic Diagram - Control Electronics




Figure 41
Left Side



Engineering & Technical Drawings (continued)

Reference Drawing # 11145-1

Schematic Diagram - Control Electronics




Figure 41
Right Side



E/01-96

Engineering & Technical Drawings (continued)

Reference Drawing # 11145-2

Schematic Diagram - Sensor Input Circuit




Figure 42



Engineering & Technical Drawings (continued)

Reference Drawing # 11150-1

Schematic Diagram - Display Board




Figure 43



E/01-96

Engineering & Technical Drawings (continued)

Reference Drawing # 11146-3

Circuit Card Assembly - Control Board




Figure 44



Engineering & Technical Drawings (continued)

Reference Drawing # 11151-2

Circuit Card Assembly - Display Board





Figure 45



E/01-96

Engineering & Technical Drawings (continued)

Reference Drawing # 11281

Outline & Terminal Connections





Figure 46



Engineering & Technical Drawings (continued)

Reference Drawing # 11280-1

Final Assembly




Figure 47


E/01-96



Ordering Information

The standard configuration for the Model TA102A is:

TA102A - 3 2 1 - 1 00 - 0 3 3





Zero Two Series Modules

Model 2602A

Zero Two Series Control Module
for Hydrogen Sulfide Gas
Applications

Model 4802A

Zero Two Series Control Module
for Combustible Gas
Applications

Model TA102A

Zero Two Series Trip Amplifier Module
for Combustible Gas
Applications

Model TA202A

Zero Two Series Trip Amplifier Module
for Hydrogen Sulfide Gas
Applications

Model TA402A

Zero Two Series Trip Amplifier Module
for Flame Detection
Applications

Model FM002A

Zero Two Series Facilities Module
Performs Common Functions
for Zero Two Systems

Model RL002

Zero Two Series Relay Module
Provides Extra Output Capacity
for Zero Two Systems

Model ZN002A

Zero Two Series Zone Control Module
Performs Zoning and Voting Functions
for Zero Two Systems

Model MD002

Zero Two Series DriverCard
for Monitoring / Driving High Current
Output Devices

Model IN042

Zero Two Series Four Zone Input Card
For Callpoints, Smoke & Thermal Detectors

Model PS002*

Zero Two Series Power Supply Module
for Zero Two Systems

* = Non-European Countries Only.



A

A1 Alarm.....	9
A2 Alarm.....	8
A2 Alarm Options.....	20, 21
AC	31
Alarm	
A1	9
A2	8
Accepting	14
Latched	15
Resetting	15
Ambient.....	31
Analog.....	31
Analog Output Signal	11, 14
Applications	2
Applying Power	12
AWG	31

B

Benefits	1
----------------	---

C

Cable Parameters	4
Calibration.....	31
Equipment	28
Open Collector	10
Calibration Check Mode.....	15
Calibration Mode	15
Canadian Standards Association	31
Card Test Options	23
Class I.....	31
Coding Strip	7
Female	7
Male.....	7
COM.....	31
Conduit.....	31
Connections	
A1 - OC	9
A1 Alarm Relay	9
A1 Mimic - OC	9
A2 Alarm - OC	8
A2 Alarm Relay	8
A2 Mimic - OC	8
Analog Minus	11
Analog Plus	11
Analog Signal.....	11
CAL - OC.....	10
Card Test Switch	11
Fault - OC.....	9
Fault Relay	9
FUA - OC	9

C

Connections	
Power.....	11
UA - OC	10
Control Module Installation.....	7
CSA	31

D

DC	31
DCS.....	31
Diffusion	31
Digital.....	31
Division 1	31
Drain Loop	31
Duct Mounting Plate.....	27
Dust Guard Assembly	27

E

EEPROM.....	31
Electrical Classification	3
Electrical Specifications	3, 4
Electromagnetic Interference.....	7
Engineering & Technical Drawings	34 through 41
Engineering Specifications	
TA102A	5
Zero Two Series	4
Environmental Specifications	4

F

Facilities Module.....	15
Fault.....	9
Fault Option	
During Inhibit Mode.....	22
Fault Unaccept	9
Feature	
Card Test	11
Features	1
Features & Benefits	
Card Test	1
LED Test	1
Live Insertion/Removal.....	1
Password Option.....	1
Setup Check Mode	1
Setup Mode.....	1
FMRC.....	31
Functional Test	
SEE ALSO	Card Test



G

General Description	1
Glossary of Terms	31, 32
Group B	31
Group C	31
Group D	31

H

Halogen Free Solvent.....	31
Heat Build-up	7
Humidity Range	4

I

Inductive Loads	9
Input Power	3
Installation	
Applying Power	12
Control Module	7
Rear Terminal Connections.....	7, 8, 9, 10, 11
Sensor Location Considerations.....	12
Upon Receipt of Equipment.....	7
Interfaces	
Display	17
Setup Check Mode	17
Setup Mode.....	22, 23, 24
Introduction	1, 2

L

Latching	14, 15, 18, 20, 21, 31
LED Test	1, 5, 15
Length.....	3

M

mA	31
Maintenance	
Calibration Checks	13
Functional Test	13
General.....	13
Mode	
Calibration	15
Calibration Check	15
Inhibit.....	20, 24
Setup	22, 23, 24
Setup Check.....	17

M

Model	
2602A	43
4802A	43
FM002A	43
IN042	43
MD002	43
PS002	43
RL002	43
TA102A	43
TA202A	43
TA402A	43
ZN002A	43
Mounting Strip	
SEE ALSO.....	Coding Strip
mV	32

N

NEC	31
-----------	----

O

Open Collector	
A1 Alarm	9, 13
A1 Mimic	9, 13
A2 Alarm	13
A2 Mimic	8, 13
CAL.....	13
Calibration Output	10
Fault	13
Fault Unaccept.....	9
Fault Unaccept (FUA)	13
Rating	3, 11, 13
Unaccept (UA).....	10, 13
Operation	
Accepting Alarm Conditions.....	14
CAL Open Collector.....	15
Electrical Inputs	13
Electrical Outputs	13, 14, 16
General Maintenance	13
Resetting Latched Alarms	15
Ordering Information	42

P

Password Option.....	19, 24
PCB	32
PLC	32
Potentiometer.....	32



R

Rear Terminal Connections 7, 9, 10, 11
 Receipt of Equipment 7
 Relay
 A1 Alarm 13
 A1 Common 9
 A1 Contact 9
 A2 Alarm 13
 A2 Contact 8
 A2, Common 8
 Contact Rating 3, 9, 13
 De-Energized A1 Alarm 9
 De-Energized A2 Alarm 8
 Energized A1 Alarm 9
 Energized A2 Alarm 8
 Fault 13
 Fault Contact 9
 NC Contact, A1 Alarm 9
 NC Contact, A2 Alarm 8
 NO Contact, A1 Alarm 9
 NO Contact, A2 Alarm 8
 Protection Circuits 9
 RFI 32

S

Sensor
 Accuracy 3
 Connections 10
 Duct Mounting Plate 27
 Dust Guard 27
 Location Considerations 12
 Placement 12
 Response 3
 Splash Guard 26
 Type 3
 Typical Life 3
 Setup Check Mode 17
 Specifications
 TA102 Control Module 5
 Accuracy 3
 Cable Parameters 4
 Electrical Classification 3
 Electrical Specifications 3
 Engineering Specifications 4
 Environmental Specifications 4
 Height 3
 Input Power Requirement 3
 Length 3
 Mechanical Specifications 3
 Open Collector Rating 3
 Operating Humidity Range 4
 Operating Temperature Range 4
 Relay Contact Rating 3
 Response Time 3
 Sensor Type 3
 Storage Temperature Range 4

S

Specifications
 System Specifications 3
 Typical Sensor Life 3
 User Protection 3
 Weight 3
 Width 3
 Splash Guard 26

T

T50 32
 TB 32
 Temperature
 Operating Range 4
 Storage Range 4
 Terminal Block
 Designations 8
 Operation 8
 Terminal Connections
 Rear 8
 Terms, Glossary 31, 32
 Test
 Card Test 1, 11
 LED Test 1

U

Unaccept Output 10
 User Interfaces
 Types 17
 User Protection 3

W

Warnings
 Approved Field Devices i
 Backwards Compatibility i
 Combustible & Flammable Gases and Vapors i
 Electro-Static Damage i, 8
 Identification i
 Safety Warning i
 Warranty Statement i
 Wire Strip Length 8

Z

Zero Two Series Modules 43