

Set-Up Your Crock-Pot® Connected Slow Cooker



STEP 1:
Download *the free
Alexa App*

Download the latest version of the Alexa App from the app store.



STEP 2:
Prep *the slow
cooker for use*

Remove all packaging components and wash the lid and stoneware.



STEP 3:
Plug in *the slow cooker*

Plug the Crock-Pot® slow cooker into an electrical outlet.



STEP 4:
Check *slow cooker
Wi-Fi® indicator*

The Wi-Fi® indicator on the Crock-Pot® slow cooker should be blinking orange and green, meaning the slow cooker is in setup mode. If this does not occur, please hold down the restore button on the side of control panel for 5 seconds.




STEP 5:
Follow *instructions
in the Alexa App*

In the Alexa app, tap the devices icon in the lower right and then add your slow cooker as a new device.



THINGS TO TRY:

Ask Alexa or press and release the  button to use voice instructions.

Cook for a Specific Time & Power

“Alexa, set the Crock-Pot to Low for 6 hours”

Changing Cook-Time

“Alexa, add 2 hours to the Crock-Pot”

Starting and Stopping Cooking

“Alexa, start the Crock-Pot”

“Alexa, turn off the Crock-Pot”

Check the Status

“Alexa, what is the setting on the Crock-Pot?”

“Alexa, when will the food be done?”

Additional information regarding your Crock-Pot® slow cooker, including compliance and safety precautions, can be found in the User Manual or at www.amazon.com/alexasupport