### Safety Notice - Stop Use



MSA Gravity® Welder Harness

January 29, 2018

MSA Corporate Center 1000 Cranberry Woods Drive Cranberry Township, PA 16066 800.MSA.2222 www.MSAsafety.com

#### **Dear MSA Fall Protection Customer,**

This Safety Notice is issued to inform you that MSA received a field report from an end user regarding select MSA Gravity Welder Harnesses and that, as a result of MSA's findings related to this report, you must take the actions outlined in this Safety Notice.

Upon investigation of the field report, MSA determined that the leg strap and chest strap used in select MSA Gravity Welder Harnesses are incompatible. Although the harness can be donned, in the event of a fall, the shoulder straps may extend and affect the protection offered by the harness.

MSA is advising all MSA Gravity Welder Harness customers to immediately stop use of affected MSA Gravity Welder Harnesses produced from July 2015 through and including January 2018. The harnesses are to be removed from service, marked "UNUSABLE" and destroyed.

#### **Identifying and Addressing Affected MSA Gravity Welder Harnesses**

Affected MSA Gravity Welder Harnesses are those marked with one of the following part numbers and a manufacturing date from July 2015 through and including January 2018.


- 10151154
- 10158954
- 10158956
- 10158957

To confirm whether or not your harness is affected, check the label on the harness for part number and manufacture date that meet the criteria above. See Figure 1 for the location of the part number and manufacture date on an MSA Gravity Welder Harness label.

If the part number has been made illegible through use, refer to Figure 2 to determine whether or not your harness is affected.

If the part number matches the list above, but the manufacturing date has been made illegible through use, consider your harness to be affected.

If your harness is affected, remove it from service, mark it "UNUSABLE" and destroy it.





**MSA Corporate Center** 

1000 Cranberry Woods Drive Cranberry Township, PA 16066 800.MSA.2222 www.MSAsafety.com

An affected MSA Gravity Harness will have no buckle on the shoulder straps and an oval ring where the shoulder straps connect to the leg straps.




Figure 2 – Affected MSA Gravity Welder Harness



**MSA Corporate Center** 

1000 Cranberry Woods Drive Cranberry Township, PA 16066 800.MSA.2222 www.MSAsafety.com

Note that MSA Gravity Welder Harnesses could also have been ordered as part of kit numbers 10026061, 10026064, 10105480 and 10103470. Harnesses that were provided within these kits are also labeled with the individual harness part number and can be identified as detailed above.

#### Replacing Affected MSA Gravity Welder Harnesses

We recognize that this in an inconvenience and in an effort to minimize any disruption, we pledge to make this replacement process as expeditious as possible.

If you are in possession of affected harnesses per the criteria above, MSA will replace them free of charge.

Complete the enclosed MSA Gravity Welder Harness Replacement Form and email it to Customer Service as indicated on the form.

Upon receipt, MSA will enter an order to provide you with a replacement for your harness.

#### **MSA Customer Service Contact Information:**

If you have any questions regarding this *Safety Notice*, please contact MSA Customer Service as follows:

- U.S., Canada, or U.S. Territories 1-866-672-0005 or by email at: ProductSafetyNotices@MSAsafety.com.
- Outside the U.S., Canada, and U.S. Territories 724-776-8626 or by email at: LAMZonecs@MSAnet.com.

We apologize for any inconveniences that this may cause; however, your safety and continued satisfaction with our products is important to us.

Best regards,

Nathan Andrulonis

Manager of Product Safety

PS18003-03

# MSA The Safety Company

## MSA Gravity Welder Harness Replacement Form

Please complete this form and email it to the appropriate MSA Customer Service address below:

- U.S., Canada, or U.S. Territories <a href="mailto:ProductSafetyNotices@MSAsafety.com">ProductSafetyNotices@MSAsafety.com</a>
- Outside the U.S., Canada, and U.S. Territories <u>LAMZonecs@MSAnet.com</u>

MSA Corporate Center 1000 Cranberry Woods Drive Cranberry Township, PA 16066 800.MSA.2222 www.MSAsafety.com

Multiple orders can be placed by submitting additional copies of this form.

Name:		
Company Name:		
Shipping Address:		
Phone:	E-Mail:	
I confirm that the MSA Gravity We have been removed from service Signature/Date:	and destroyed.	by the January 29, 2018 Safety Notice
	Part Number	Quantity
Please indicate the following for the replacement harnesses that are being requested:		

MSA Use Only - Order Code: UR3 PS18003-03