

Product Information News

January 22, 2009

REMOVAL OF APPLICATION OF CHRISTO-LUBE FROM NIPPLE O-RING IN C.A.R.E. MANUALS

This PIN Article is to inform C.A.R.E. certified repair persons of a change in maintenance procedures in C.A.R.E. manuals and parts lists regarding the removal of instructions to apply Christo-Lube to the nipple o-ring (P/N 633533).

Testing indicates that the presence of Christo-Lube on the nipple o-ring has a negligible effect on the performance of the o-ring.



Detail of Audi-Larm Audible Alarm with nipple o-ring.

There is no reason to replace o-rings lubricated with Christo-Lube, or to clean Christo-Lube from o-rings on in-service air masks.

C.A.R.E. Manuals will reflect this change in their next revision, as needed. Affected manuals include, but are not limited to,

- 10042833 Audi-Larm™ Audible Alarm Maintenance and Repair
- 10093084 FireHawk® M7 Audi-Larm Audible Alarm Maintenance and Repair
- 10088637 FireHawk M7 Air Mask Parts List
- 10088637 FireHawk M7 Air Mask
- FireHawk M7 Responder® Air Mask Parts List

For More Information, call 1-800-MSA-2222 or Visit Our Website at www.MSAnet.com