

# Confidence Plus™ Germicidal Cleaner



A one-step disinfectant, cleaner, and deodorant for nonporous surfaces of PPE (personal protective equipment).

MSA's Confidence Plus Germicidal Cleaner is one of the most economical yet effective germicidal detergent formulations available. Just mix 1 oz. of the cleaner with 1 gallon of warm water (110°F maximum) for a clear, stable solution for cleaning, sanitizing, and disinfecting hard nonporous surfaces of personal safety equipment.

- Makes 32 gallons of disinfectant
- Includes built-in measuring cup for easy mixing
- Use on hard hats, faceshields, goggles, spectacles, protective headgear, hearing protectors, gas masks, SCBA

Note: Follow the use instructions provided with the safety equipment to avoid damaging the equipment. Surfaces should be rinsed in clean water and air-dried prior to reuse.

Cleanup is fast. Just remove the cap from the measuring cup and squeeze the container until the measuring cup is filled with cleaner. Mix with warm water. Immerse the soiled item in the solution and scrub gently with a soft brush until clean. Rinse thoroughly in clean water and allow to dry. Contact time necessary for use as a disinfectant is 10 minutes.

## Ordering Information

| Part No. | Description                        |
|----------|------------------------------------|
| 10009971 | Confidence Plus Germicidal Cleaner |

## Approvals and Standards

This disinfectant is effective against a wide variety of gram-negative and gram-positive organisms. It kills: salmonella choleraesuis, staphylococcus aureus, pseudomonas aeruginosa, serratia marcescens, human immunodeficiency virus (HIV-1), Influenza virus, Herpes Simplex, and Vaccinia. Confidence Plus is registered with the Federal EPA and tested by independent laboratories using current A.O.A.C. use-dilution methods. EPA Registration Number 2212-16-4204. EPA Establishment Registration Number 2212-NY-1.



## ⚠ WARNING

Avoid contamination of food. Causes eye irritation. Avoid contact with skin.  
May cause skin irritation. In case of contact, flush with water. If irritation persists, get medical attention.

### Active Ingredients:

N-alkyl (50% C14, 40% C12, 10% C16) dimethyl benzyl ammonium chloride . . . . . 5%

Inert Ingredients: . . . . . 95%

**Note:** This Bulletin contains only a general description of the products shown. While uses and performance capabilities are described, under no circumstances shall the products be used by untrained or unqualified individuals and not until the product instructions including any warnings or cautions provided have been thoroughly read and understood. Only they contain the complete and detailed information concerning proper use and care of these products.



ID 1001-24-MC / April 2007

© MSA 2007 Printed in U.S.A.

**Corporate Headquarters**  
P.O. Box 426, Pittsburgh, PA 15230 USA  
Phone 412-967-3000  
[www.MSAnet.com](http://www.MSAnet.com)

**U.S. Customer Service Center**  
Phone 1-800-MSA-2222  
Fax 1-800-967-0398

**MSA Canada**  
Phone 416-620-4225  
Fax 416-620-9697

**MSA Mexico**  
Phone 52-55 21 22 5770  
Fax 52-55 5359 4330

**MSA International**  
Phone 412-967-3354  
FAX 412-967-3451

**Offices and representatives worldwide**  
For further information:

**MSA**  
The Safety Company™