



GE HealthCare

Power Solutions

Imaging Accessories & Supplies



Reliable



Compatible



One-Stop Shop

How to Order



Available 24/7, GE HealthCare Service Shop makes ordering supplies online fast and easy.

- Search real-time inventory of compatible, OEM products
- Take advantage of Auto Reorder for parts you buy regularly
- Batch order multiple items at once with Quick Order
- Get instant order and tracking confirmations
- Pay by PO or credit card or integrate your purchasing system

Visit GE HealthCare Service Shop to register.

1. Visit GE HealthCare Service Shop, navigating to the registration link in the upper left-hand corner of the page.
2. Give us your account details. Pro tip: Provide your customer account number for expedited registration.
3. A welcome message will come to you through the email you provide. Start shopping!

Register now at ServiceShop.GEHealthcare.com

Other ways to order:



Phone: (866) 281-7545 Options 1, 2, 1, 2

Fax: (877) 279-6990

Email: gehcaccessorysales@ge.com

EDI: Free – contact us for details

Hours: 7AM – 6PM (CST)



Table of Contents

Uninterruptible Power Supplies.....	PS 4	▶
Transformer.....	PS 6	▶
Dynamic Sag Corrector.....	PS 7	▶
Main Disconnect Panels.....	PS 8	▶
AC Lighting Controllers.....	PS 10	▶
Power Quality Analyzer.....	PS 10	▶
Power Quality Compatibility Guide.....	PS 11	▶



See Power Quality Compatibility Guide
on page PS 11-15

Uninterruptible Power Supplies

Uninterruptible Power Supplies (UPS)

- Helps provide reliable, clean, consistent power for Diagnostic Imaging and PACS systems
- Helps to eliminate power anomalies (noise, transients, over and undervoltage), which could damage the system's sensitive computer components
- Enables the DI system to complete scanning after the loss of supply power and allows for the saving of valuable data and orderly system shutdown
- GE HealthCare tests and approves the UPSs listed in this catalog for compatibility with GE HealthCare Diagnostic imaging systems. All solutions are On-Line Double Conversion UPS.
- Configurations are available to support multi-modalities or even complete departments



Cat#	Description	Warranty
CT UPS		
E4582AF	Riello 100 kVA UPS (non-seismic)	O
E4582AG	Riello 160 kVA UPS (non-seismic)	O
E4582AK	Riello 100 kVA UPS (seismic)	O
E4582AL	Riello 160 kVA UPS (seismic)	O
E4582AH	Riello 200 kVA UPS (non-seismic)	O
E4582AM	Riello 200 kVA UPS (seismic)	O
E4502WA	Eaton 150 kW 93PM (non-seismic) UPS, non-upgradeable, 6.1 min runtime	O
E4502WB	Eaton 150 kW 93PM (seismic) UPS, non-upgradeable, 6.1 min runtime	O
E4502WF	Eaton 200 kW 93PM (non-seismic) UPS, non-upgradeable, 4.1 min runtime	O
E4502WG	Eaton 200 kW 93PM (seismic) UPS, non-upgradeable, 4.1 min runtime	O
E4502F	Eaton 14 kVA Partial UPS	O
E4502KZ	Liebert 10 kVA Partial UPS	O
E4504CP	Eaton 15 kVA Partial UPS	O
E4502YA	Eaton Seismic Kit for Cat# E4502F and E4502KY UPS	O

Cat#	Description	Warranty
PET UPS		
E4582AF	Riello 100 kVA UPS (non-seismic)	O
E4582AG	Riello 160 kVA UPS (non-seismic)	O
E4502WA	Eaton 150 kW UPS (non-seismic)	O
E4502WB	Eaton 150 kW UPS (seismic OHSPD)	O
E4502F	Eaton 14 kVA Partial UPS	G
E4502YA	Eaton Seismic Kit for Cat# E4502F	O
MR UPS		
E4504FP	Eaton 0.7 kVA Partial System UPS	O
E4502WA	Eaton 93PM 150 kW UPS (non-seismic)	O
E4502WB	Eaton 93PM 150 kW UPS (seismic OSHPD)	O
E4582AF	Riello UL UPS MHT 100 kVA three phase (non-seismic)	O
E4582AK	Riello UL UPS MHT 100 kVA, three phase, Seismic option	O
E4582AG	Riello UL UPS MHT 160 kVA three phase (non-seismic)	O
E4582AL	Riello UL UPS MHT 160 kVA, three phase (seismic option)	O
E4582AH	Riello UL UPS MHT 200 kVA, three phase (non-seismic)	O
E4582AM	Riello UL UPS MHT 200 kVA, three phase (seismic version)	O
E4582AJ	Riello UL UPS MHT 300 kVA, three phase, 4 min runtime	O
E4502DA	ABB TLE UPS 80KW UPS (non-seismic)	O



See Power Quality Compatibility Guide on page PS 11-15

Uninterruptible Power Supplies (UPS) *(cont.)*

Cat#	Description	Warranty
Interventional UPS		
E4502WA	Eaton 150 kW 93PM (non-seismic) UPS, non-upgradeable, 6.1 min runtime	O
E4502WB	Eaton 150 kW 93PM (seismic) UPS, non-upgradeable, 6.1 min runtime	O
E4582AG	Riello MHT 160 kVA UPS (non-seismic)	O
E4582AL	Riello MHT 160 kVA UPS (seismic)	O
Nuclear Medicine UPS		
E4582AF	Riello 100 kVA UPS (non-seismic)	O
E4582AG	Riello 160 kVA UPS (non-seismic)	O
E4582AK	Riello UL UPS MHT 100 kVA, three phase, Seismic Option ABB	O
E4502KX	Powercom 1.5 kVA VGS-1500 UPS for Discovery 750b	O
E4502FL	Vertiv 10 kVA UPS (three-phase)	
E4502KZ	Vertiv Liebert 10kVA CT partial UPS	O
E4502JJ	Eaton 6 kVA Eaton UPS	O
E4502KV	Powercom VGS-2000 2 kVA UPS, 120V, 50/60 Hz for Discovery NM530c	G
E4502YB	Eaton Seismic Kit for Cat# E4502JJ UPS	O
E4502WL	Eaton 93PM 100 kW UPS (non-seismic)	O
E4502WM	Eaton 93PM 100 kW UPS (seismic OSHPD)	O
E4502KX	Powercom 1.5 kVA UPS	O
RAD/R&F UPS		
E4582AF	Riello MHT 100 kVA, three phase, (non-seismic)	O
E4582AK	Riello UL UPS MHT 100 kVA, three phase, Seismic option	O
E4502WA	Eaton 150 kW 93PM (non-seismic) UPS, non-upgradeable, 6.1 min runtime	O
E4502WB	Eaton 150 kW 93PM (seismic) UPS, non-upgradeable, 6.1 min runtime	O
E4504FQ	Eaton 0.7 kVA Partial System UPS	O
E4502WL	Eaton 93PM 100 kW UPS (non-seismic)	O
E4502WM	Eaton 93PM 100 kW UPS (seismic OSHPD)	O
Mammography UPS		
E4502JJ	Eaton 6 kVA, 208V, Single Phase UPS (Senographe Pristina only)	O
E4502JV	Vertiv Liebert GXT5 10 kVA, 208VAC, 1 Phase, online double conversion UPS, with 3 years warranty	O
Lunar UPS		
E4502LB	1.5 kVA UPS for LUNAR iDXA and Prodigy Systems (also requires E4502LC grounding kit)	G
E4502LC	Cable Kit for Cat# E4502LB UPS	G
Multi-System UPS		
E4502DD	250 kW UPS (non-seismic)	O



See Power Quality Compatibility Guide
on page PS 11-15

Transformer

Transformer

- Meets or exceeds DOE 2016, NEMA TP-1, NEMA premium and DOD CSL-3 efficiency requirements
- Qualified to the seismic requirements of ASCE7.05, IEEE-693-2005 and IBC-2006
- UL Listed



Cat#	Description	Warranty
E4500TB	112.5 kVA Step Up Transformer – 208-480Y/277 Volt	Y



See Power Quality Compatibility Guide on page PS 11-15

Dynamic Sag Corrector

Dynamic Sag Corrector (DySC)

- Corrects for voltage sags at the system, department or facility level
- DySC is optimized for fast sag detection and response time (voltage detect time of 1 ms; sags are corrected with a peak voltage response time of 1.5 ms)
- A green power solution at > 99% energy efficiency, the DySC has no batteries and over time can offer lower cost of maintenance
- Smaller footprint and lighter weight than comparable (kVA) UPS systems
- Service Contracts offered by GE HealthCare



E4502SJ

Cat#	Description	Warranty
E4505SJ	200 Amp (166 kVA) ProDySC Dynamic Sag Corrector (without installation)	Y
E4505SM	200 Amp GT (166 kVA) ProDySC Dynamic Sag Corrector (without installation)	Y

Main Disconnect Panels

Main Disconnect Panels

- Main Disconnect Panels provide emergency shut down, undervoltage protection, overcurrent protection, OSHA lockout tag provisions, and serves as a local disconnect for the GE HealthCare Diagnostic Imaging System.
- Helps reduce installation time by providing a single-point power connection, eliminating the need to mount and wire a number of individual components
- Standardized design and testing helps ensure high product quality and system reliability
- UL and cUL listed for compliance with National Electric Code
- Surface or semi-flush mounting
- Please consult your GE HealthCare Field Engineer to determine if this is the appropriate product for your needs before purchasing



E4502BB/BC/BE/BF

Cat#	Description	Warranty
RAD/R&F Main Disconnect Panels		
E4502RP	25 KAIC X-Ray Main Disconnect Panel 90 Amp, Auto-Restart	Y
E4502ST	25 KAIC X-Ray Main Disconnect Panel 80 Amp, 480 V/208 V	Y
E4502RS	25 KAIC X-Ray Main Disconnect Panel 110 Amp, 480 V/208 V	Y
E4502RT	25 KAIC X-Ray Main Power Disconnect Panel - 150 Amp, 480V/208V	Y
E4502JH	X-ray Main Power Disconnect Panel - 225 Amp, 480V/208V	Y
E4502RY	25 KAIC X-Ray Main Disconnect Panel 125 Amp, Auto-Restart	Y
E4502TA	Main Disconnect Panel for Definium XR/f - UL 150A, 50KW, 208V, 60Hz, single phase with externally mounted 100 kVA step-up transformer	Y
E4502TB	Main Disconnect Panel for Definium XR/f - UL 150A, 50KW, 240V, 60Hz, single phase	Y
E4502TC	Main Disconnect Panel for Definium XR/f - UL 40A, 50KW, 480V, 60Hz, 3 phase	Y
E4502TD	Main Disconnect Panel for Definium XR/f - UL 50A, 65KW, 480V, 60Hz, 3 phase	Y
E4502TE	Main Disconnect Panel for Definium XR/f - UL 60A, 80KW, 480V, 60Hz, 3 phase	Y
CT Main Disconnect Panels		
E4502BB	CT Main Disconnect Panel 90A 380-480VAC 50/60Hz 3 phases	Y
E4502BE	CT Main Disconnect Panel 125A 380-480VAC 50/60Hz 3 phases	Y
E4502BG	CT Main Disconnect Panel 175A 380-480VAC 50/60Hz 3 phases for Revolution Apex	Y



See Power Quality Compatibility Guide
on page PS 11-15

Main Disconnect Panels *(cont.)*

Cat#	Description	Warranty
Nuclear Medicine/PET Main Disconnect Panels		
E4502BB	CT Main Disconnect Panel 90A 380-480VAC 50/60Hz 3 phases	Y
E4502BC	CT Main Disconnect Panel 110A 380-480VAC 50/60Hz 3 phases	Y
E4502BE	CT Main Disconnect Panel 125A 380-480VAC 50/60Hz 3 phases	Y
E4502BF	CT Main Disconnect Panel 150A 380-480VAC 50/60Hz 3 phases	Y
E4502BG	CT Main Disconnect Panel 175A 380-480VAC 50/60Hz 3 phases for Revolution Apex	Y
Mammography Main Disconnect Panels		
E4502PA	Main Disconnect Panel for the Senographe Pristina/Essential/DS (208-240V, 50/60 Hz, UL)	Y
Interventional Main Disconnect Panels		
E46001BD	Main Disconnect Panel – UL, OSHPD, 100 Amp, 480 VAC, 60 Hz, 3-phase	Y



See Power Quality Compatibility Guide
on page PS 11-15

AC Lighting Controllers

AC Lighting Controllers

- “X-ray in Use” warning and room lighting control panel provide a low voltage interface between the “X-ray in Use” warning lights, interior room general lighting systems and the X-ray system
- Convenient, push on/off pre-wired footswitch for control of room general lighting
- Enhances servicing safety by the use of a low voltage interface circuit between the imaging system and the line voltage lighting system



E4502SS

Cat#	Description	Warranty
E4502SS	X-ray Warning and Room Lighting Control Panel (X-ray, Vascular, R&F)	Y
E4502RL	X-ray Warning Light Control Panel (CT, MR, X-ray)	Y



See Power Quality Compatibility Guide
on page PS 11-15

Power Quality Analyzer

POWERSIDE PQube 3 Power Quality and Environmental Analyzer

PQube® 3 is an instrument for monitoring electric power systems and environmental conditions, designed to help solve problems that impact the quality and reliability of the medical equipment.

- Records disturbances on the modality supply: sags/dips, swells, interruptions, frequency variations, impulses, and waveform events
- It also records power quality parameters like flicker, unbalance, current and voltage THD (harmonics) and current and voltage harmonics (THD, TDD)
- Implementing a POWERSIDE PQube 3 in your facility will help identify your power anomalies and degradations. Once identified, we can help you find a power solution to solve problems that impact the quality and reliability of your medical equipment.



E45041BK

Cat#	Description	Warranty
E45041BK	POWERSIDE PQube® 3 Power Quality and Environmental Monitoring System. Stationary Package for Medical Equipment	O



See Power Quality Compatibility Guide
on page PS 11-15

Power Quality Compatibility Guide

CT Systems	Full UPS Cat #	Full UPS Description	Partial UPS Cat #	Partial UPS Description	Maintenance Bypass Panel	Main Disconnect Panel	AC Lighting Controller
Revolution ACTs, Revolution ACT	Check with your local GE HealthCare representative.						E4502SS E4502RL
Revolution Maxima (72kW), ACE/Optima CT680 Expert, Revolution EVO, Revolution ACE ES (72 kW), Maxima 55kW, CT Ascend (72kW)	E4502WL	Eaton 93PM 100 kW UPS (non-seismic)	E4502KZ	Vertiv Liebert GXT4-GE 10 kVA Partial System UPS (GE HealthCare specific package)	E4502WL/WM configurations include their own MBP and a wall-mounted load distribution panel. Riello offers a free-standing and a wall-mounted panel E4582BF – Wall-mount E4582BK – Free-standing	E4502BB 90A	E4502SS E4502RL
	E4502WM	Eaton 93PM 100 kW UPS (seismic OSHPD)					
	E4582AF	Riello UL UPS MHT 100 kVA three phase (non-seismic)					
	E4582AK	Riello UL UPS MHT 100 kVA, three phase, Seismic option					
Optima CT540	E4502WL	Eaton 93PM 100 kW UPS (non-seismic)	E4502KZ	Vertiv Liebert GXT4-GE 10 kVA Partial System UPS (GE HealthCare specific package)	E4502WL/WM configurations include their own MBP and a wall-mounted load distribution panel. Riello offers a free-standing and a wall-mounted panel E4582BF – Wall-mount E4582BK – Free-standing	E4502BB 90A	E4502SS E4502RL
	E4502WM	Eaton 93PM 100 kW UPS (seismic OSHPD)					
	E4582AF	Riello UL UPS MHT 100 kVA three phase (non-seismic)					
	E4582AK	Riello UL UPS MHT 100 kVA, three phase, Seismic Option					
Optima CT520, Optima CT520 Series with DoD16, Revolution Advance/Eagle	E4502WL	Eaton 93PM 100 kW UPS (non-seismic)	E4502KZ	Vertiv Liebert GXT4-GE 10 kVA Partial System UPS (GE HealthCare specific package)	E4502WL/WM configurations include their own MBP and a wall-mounted load distribution panel. Riello offers a free-standing and a wall-mounted panel E4582BF – Wall-mount E4582BK – Free-standing	E4502BB 90A	E4502SS E4502RL
	E4502WM	Eaton 93PM 100 kW UPS (seismic OSHPD)					
	E4582AF	Riello UL UPS MHT 100 kVA three phase (non-seismic)					
	E4582AK	Riello UL UPS MHT 100 kVA, three phase, Seismic Option					
Revolution Frontier/ES	E4502WA	Eaton 93PM 150 kW UPS (non-seismic)	E4502F and add E4502YA UPS Seismic Kit if needed	Eaton 9355-15- 14GE 14.4k VA Partial System UPS (GE HealthCare specific package)	E4502WA/WB configurations include their own MBP and a wall-mounted load distribution panel. Riello offers a free-standing and a wall-mounted panel E4582BF – Wall-mount E4582BK – Free-standing	E4502BE 125A	E4502SS E4502RL
	E4502WB	Eaton 93PM 150 kW UPS (seismic OSHPD)					
	E4582AG	Riello UL UPS MHT 160 kVA three phase (non-seismic)					
	E4582AL	Riello UL UPS MHT 160 kVA, three phase, Seismic option					
CT Cardiographie	E4502WA	Eaton 93PM 150 kW UPS (non-seismic)	E4504CP (requires UPS cables and install procedure B7666BC)	15kVA Partial System UPS	E4502WA/WB configurations include their own MBP and a wall-mounted load distribution panel. Riello offers a free-standing and a wall-mounted panel E4582BF – Wall-mount E4582BK – Free-standing	E4502BE 125A	E4502SS E4502RL
	E4502WB	Eaton 93PM 150 kW UPS (seismic OSHPD)					
	E4582AG	Riello UL UPS MHT 160 kVA three phase (non-seismic)					
	E4582AL	Riello UL UPS MHT 160 kVA, three phase, Seismic option					
Revolution CT/CT ES upgradeable to Apex, Revolution Apex	E4502WA	Eaton 93PM 150 kW UPS (non-seismic)	E4502F and add E4502YA UPS Seismic Kit if needed	Eaton 9355-15- 14GE 14.4k VA Partial System UPS (GE HealthCare specific package)	E4502WA/WB configurations include their own MBP and a wall-mounted load distribution panel. Riello – offers a free-standing and a wall-mounted panel E4582BG – Wall-mount E4582BL – Free-standing	E4502BE 125A	E4502SS E4502RL
	E4502WB	Eaton 93PM 150 kW UPS (seismic OSHPD)					
	E4582AG	Riello UL UPS MHT 160 kVA three phase (non-seismic)					
	E4582AL	Riello UL UPS MHT 160 kVA, three phase, Seismic option					
Revolution CT upgradeable to Apex, Revolution Apex, Revolution Apex Pro	E4502WF	Eaton 93PM 200 kW UPS (non-seismic, non-upgradeable)	E4502F and add E4502YA UPS Seismic Kit if needed	Eaton 9355-15- 14GE 14.4k VA Partial System UPS (GE HealthCare specific package)	E4502WF/WG configurations include their own MBP and a wall-mounted load distribution panel. Riello – offers a free-standing and a wall mounted panel E4582BH – Wall-mount E4582BM – Free-standing	E4502BG 175A	E4502SS E4502RL
	E4502WG	Eaton 93PM 200 kW UPS (OSHPD, non-upgradeable)					
	E4582AH	Riello 200 kVA (non-seismic)					
	E4582AM	Riello 200 kVA (Seismic)					
Revolution ASPIRE ES/Select/ Plus/Elite	Contact your local GE HealthCare representative.		Contact your local GE HealthCare representative.				E4502SS E4502RL

E4502KZ includes the seismic kit.

*E4502YA is the seismic bracket for E4502F. E4502YB is the seismic bracket for E4502JJ.

Nuclear Medicine & Nuclear Medicine Systems	Full UPS Cat #	Full UPS Description	Partial UPS Cat #	Partial UPS Description	Maintenance Bypass Panel	Main Disconnect Panel
VG (Millenium VG), Infinia, Infinia II, Infinia Hawkeye	E4502FL	Vertiv EXS 10 kVA UPS three phases				E4502SN
Optima NM/CT 640	Contact your local GE Healthcare representative.		E4502JJ + H3100YY trans- former & cables kit (E4502YB UPS seismic kit)	6 kVA UPS		E4502SU
Ventri Systems	E4502KV E4502FL	Powercom 2 kVA UPS Vertiv EXS 10 kVA UPS three phase				
Discovery NM530c, MyoSPECT	E4502KV	Powercom 2 kVA UPS				
Discovery NM 830, Discovery NM630, Brivo NM615	E4502JJ (E4502YB UPS seismic kit)	Eaton 6 kVA UPS				E4502SV
Discovery NMCT 670/870/870DR, Discovery NMCT 670CZT/870 CZT	E4502WL E4502WM E4582AF E4582AK	Eaton 93PM 100 kW UPS (non-seismic) Eaton 93PM 100 kW UPS (seismic OSHPD) Riello UL UPS MHT 100 kVA three phase (non-seismic) Riello UL UPS MHT 100 kVA, three phase, Seismic Option ABB	E4502JJ + H3100YY transformer & cables kit (E4502YB UPS seismic kit) E4502KZ	E4502JJ 6 kVA UPS for NM part – requires H3100YT cable set E4502KZ 10 kVA UPS for CT part	E4502WL/WM configurations include their own MBP and a wall-mounted load distribution panel. Riello offers a free-standing and a wall-mounted panel E4582BF – Wall-mount E4582BK – Free-standing	E4502AG 90A E4502AH 110A
Starguide	E4502WL E4502WM E4582AF E4582AK	Eaton 93PM 100 kW UPS (non-seismic) Eaton 93PM 100 kW UPS (seismic OSHPD) Riello UL UPS MHT 100 kVA three phase (non-seismic) Riello UL UPS MHT 100 kVA, three phase, Seismic Option ABB	Eaton-PW 9355-15-14GE 14.4kVA CT & NM partial UPS for Starguide and PET/CTE4502JJ + H3100YY transformer & cables kit (E4502YB UPS seismic kit) E4502KZ	E4502JJ (Eaton) 6 kVA UPS for NM part - requires H3100YT cable set E4502KZ VERTIV Liebert GXT4 10kVA CT partial UPS	E4502WL/WM configurations include their own MBP and a wall-mounted load distribution panel. Riello offers a free-standing and a wall-mounted panel E4582BF – Wall-mount E4582BK – Free-standing	E4502AG 90A E4502AH 110A
NMCT 850/860 series	E4502WL E4502WM	Eaton 93PM 100 kW UPS (non-seismic) Eaton 93PM 100 kW UPS (seismic OSHPD)	E4502YA UPS (Seismic Kit)	E4502JJ 6 kVA UPS for NM part – requires H3100YT cable set E4502KZ 10 kVA UPS for CT part	E4502DA configura- tion includes its own wall-mounted MBP.	E4502AG 90A E4502AH 110A
Discovery 750b	E4502KX	Powercom 1.5 kVA UPS				
Xeleris, Xeleris View, Entegra, Genie P&R	E4502KV	Powercom 2 kVA UPS				
Xpert (Elscint)	E4502KV	Powercom 2 kVA UPS				
POWERstation LNX	E4502KV	Powercom 2 kVA UPS				

*E4502YA is the seismic bracket for E4502F.

PET & PET/CT Systems	Full UPS Cat #	Full UPS Description	Partial UPS Cat #	Partial UPS Description	Maintenance Bypass Panel	Main Disconnect Panel	AC Lighting Controller
Discovery IQ, Discovery MI, Discovery MI/DR	E4502WL	Eaton 93PM 100 kW UPS (non-seismic)	E4502F (E4502CA UPS Long Cable Kit & E4502YA UPS Seismic Kit)	Eaton 9355-15-14GE 14.4kVA Partial System UPS (GE HealthCare specific package)	E4502WL/WM configurations include their own MBP and a wall-mounted load distribution panel. Riello offers a free standing and a wall mounted panel E4582BF – Wall-mount E4582BK – Free-standing	E4502BB 90A	E4502SS E4502RL
	E4502WM	Eaton 93PM 100 kW UPS (seismic OSHPD)					
	E4582AF	Riello UL UPS MHT 100 kVA three phase (non-seismic)					
	E4582AK	Riello UL UPS MHT 100 kVA, three phase, Seismic Option					
Omni Legend	E4502WL	Eaton 93PM 100 kW UPS (non-seismic)	E4502F (E4502CA UPS Long Cable Kit & E4502YA UPS Seismic Kit)	Eaton 9355-15-14GE 14.4kVA Partial System UPS (GE HealthCare specific package)	E4502WL/WM configurations include their own MBP and a wall-mounted load distribution panel. Riello offers a free standing and a wall mounted panel E4582BF-Wall-mount E4582BK-Free-standing	E4502BE 125A	E4502SS E4502RL
	E4502WM	Eaton 93PM 100 kW UPS (seismic OSHPD)					
	E4582AF	Riello UL UPS MHT 100 kVA three phase (non-seismic)					
	E4582AK	Riello UL UPS MHT 100 kVA, three phase, Seismic Option					

MR Systems	Full UPS Cat #	Full UPS Description	Partial UPS Cat #	Partial UPS Description	Maintenance Bypass Panel	Main Disconnect Panel
Brivo MR355, Optima MR360, SIGNA Creator, SIGNA Explorer, SIGNA Prime	E4502DA	ABB TLE UPS 80KW UPS (non-seismic)	E4504FP + E4504FN power cable	0.7 kVA Partial System UPS	E4502DA configuration includes its own wall-mounted MBP	M50022MC
SIGNA Voyager, SIGNA Pioneer, SIGNA Hero	E4502DB E4582AF E4582AK	ABB TLE UPS 100KW (non-seismic) Riello UL UPS MHT 100 kVA three phase (non-seismic) Riello UL UPS MHT 100 kVA, three phase, Seismic option	E4504FP + E4504FN power cable	0.7 kVA Partial System UPS	E4502DB configuration includes its own wall-mounted MBP. Riello offers a free standing and a wall-mounted panel E4582BF-Wall-mount E4582BK-Free- standing	M70022MC
Discovery 450 1.5T, Discovery 750 3.0T, Optima 450w, SIGNA Artist, Discovery 750w, SIGNA Architect	E4502WA E4502WB E4582AG E4582AL	Eaton 93PM 150 kW UPS (non-seismic) Eaton 93PM 150 kW UPS (seismic OSHPD) Riello UL UPS MHT 160 kVA three phase (non-seismic) Riello UL UPS MHT 160 kVA, three phase, Seismic option	E4504FP + E4504FN power cable	0.7 kVA Partial System UPS	E4502WA/WB configurations include their own MBP and a wall-mounted load distribution panel. Riello offers a free standing and a wall-mounted panel E4582BG-Wall -mount E4582BL-Free- standing	M7000ZA
Artist EVO	E4502WA E4502WB E4582AG E4582AL	Eaton 93PM 150 kW UPS (non-seismic) Eaton 93PM 150 kW UPS (seismic OSHPD) Riello UL UPS MHT 160 kVA three phase (non-seismic) Riello UL UPS MHT 160 kVA, three phase, Seismic option	E4504FP + E4504FN power cable	0.7 kVA Partial System UPS	E4502WA/WB configurations include their own MBP and a wall-mounted load distribution panel. Riello offers a free standing and a wall mounted panel E4582BG-Wall -mount E4582BL-Free standing	M7000ZA
SIGNA PET/MR	E4502DD E4582AH E4582AM	ABB TLE 250 kW UPS (non-seismic) Riello UL UPS MHT 200 kVA, three phase (non-seismic) Riello UL UPS MHT 200 kVA, three phase (Seismic version)	E4504FP + E4504FN power cable	0.7 kVA Partial System UPS	ABB E4502DD configuration includes its own wall-mounted MBP. Riello E4582BH - Wall-mount bypass panel Riello E4582BM - Free standing bypass panel (cabinet)	M8000PH
SIGNA Premier XT	E4582AJ	Riello UL UPS MHT 300 kVA, three phase, 4 min runtime	E4504FP + E4504FN power cable	0.7 kVA Partial System UPS	ABB MBP included in E45071AC Riello E4582BJ Wall-mount bypass panel Riello E4582BN Free standing bypass panel	M7100AA
SIGNA Premier	E4582AH E4582AM	Riello UL UPS MHT 200 kVA, three phase (non-seismic) Riello UL UPS MHT 200 kVA, three phase (Seismic version)	E4504FP + E4504FN power cable	0.7 kVA Partial System UPS	ABB E4502DD configuration includes its own wall-mounted MBP. Riello E4582BH - Wall-mount bypass panel Riello E4582BM - Free standing bypass panel (cabinet)	M7101MD M7100MD

*To order contact your local GE HealthCare representative.

Interventional Systems	Full UPS Cat #	Full UPS Description	Partial UPS Cat #	Partial UPS Description	Maintenance Bypass Panel	Main Disconnect Panel	AC Lighting Controller
Innova IGS 6	E4502WA	Eaton 93PM 150 kW UPS (non-seismic)	Contact your local GE HealthCare representative		E4502WA/WB configurations include their own MBP and a wall-mounted load distribution panel. Riello offers a free standing and a wall mounted panel E4582BG – Wall-mount E4582BL – Free-standing	E46001BD (OHSPD) replacing E46001BA (non-OSHDP)	E4502SS E4502RL
	E4502WB	Eaton 93PM 150 kW UPS (seismic OSHPD)					
	E4582AG	Riello UL UPS MHT 160 kVA three phase (non-seismic)					
	E4582AL	Riello UL UPS MHT 160 kVA, three phase, Seismic Option					
Allia IGS 3, Allia IGS 5 (Pulse or non Pulse)	E4502WA	Eaton 93PM 150 kW UPS (non-seismic)	Contact your local GE HealthCare representative		E4502WA/WB configurations include their own MBP and a wall-mounted load distribution panel. Riello offers a free standing and a wall mounted panel E4582BG – Wall-mount E4582BL – Free-standing		E4502SS E4502RL
	E4502WB	Eaton 93PM 150 kW UPS (seismic OSHPD)					
	E4582AG	Riello UL UPS MHT 160 kVA three phase (non-seismic)					
	E4582AL	Riello UL UPS MHT 160 kVA, three phase, Seismic Option					
Allia IGS 7, Allia IGS 7 OR (Pulse and non Pulse)	E4502WA	Eaton 93PM 150 kW UPS (non-seismic)	Contact your local GE HealthCare representative		E4502WA/WB configurations include their own MBP and a wall-mounted load distribution panel. Riello offers a free standing and a wall mounted panel E4582BG – Wall-mount E4582BL – Free-standing		E4502SS E4502RL
	E4502WB	Eaton 93PM 150 kW UPS (seismic OSHPD)					
	E4582AG	Riello UL UPS MHT 160 kVA three phase (non-seismic)					
	E4582AL	Riello UL UPS MHT 160 kVA, three phase, Seismic Option					

X-ray System	Full UPS Cat #	Product Description	Partial UPS Cat #	Product Description	Maintenance Bypass Panel	Main Disconnect Panel	AC Lighting Controller
50 kw Generator Definium 656 HD Definium Tempo Pro/Plus Definium Pace Select Optima 646 HD Optima 646	E4502WL	Eaton 93PM 100 kVA UPS (non-seismic)	*E4504FQ	0.7 kVA Partial System UPS (* indicates approval for use with these systems)	E4502WL/WM Configurations include their own MBP and a wall-mounted load distribution panel. Riello - offers a free standing and a wall-mounted panel E4582BF-Wall-mount E4582BK-Free- standing	E4502RP - 90 Amp, Auto Restart E4502ST- 80 Amp E4502RS - 110 Amp E4502RT- 150 Amp E4502JH - 225 Amp E4502RY - 125 Amp, Auto Restart	E4502SS E4502RL
	E4502WM	Eaton 93PM 100 kVA (seismic OSHPD)					
	E4582AF	Riello MHT 100 kVA three phase (non-seismic)					
	E4582AK	Riello UL UPS MHT 100 kVA, three phase, Seismic option					
65 kw Generator Definium 656 HD Definium Tempo Pro/Plus Definium Pace Select Optima 646 HD Optima 646	E4502WL	Eaton 93PM 100 kVA UPS (non-seismic)	E4504FQ	0.7 kVA Partial System UPS	E4502WL/WM Configurations include their own MBP and a wall-mounted load distribution panel. Riello - offers a free standing and a wall-mounted panel. E4582BF-Wall-mount E4582BK-Free-standing	E4502RP - 90 Amp, Auto Restart E4502ST- 80 Amp E4502RS - 110 Amp E4502RT- 150 Amp E4502JH - 225 Amp E4502RY - 125 Amp, Auto Restart	E4502SS E4502RL
	E4502WM	Eaton 93PM 100 kVA (seismic OSHPD)					
	E4582AF	Riello MHT 100 kVA three phase (non-seismic)					
	E4582AK	Riello UL UPS MHT 100 kVA, three phase, Seismic option					
80 kw Generator Definium 656 HD Definium Tempo Pro/Plus Definium Pace Select Optima 646 HD Optima 646	E4502WA	Eaton 93PM 150 kVA UPS (non-seismic)			E4502WA/WB Configurations include their own MBP and a wall-mounted load distribution panel. Riello - offers a free standing and a wall-mounted panel E4582BG-Wall-mount E4582BL-Free- standing	E4502TA 50KW 208V 60Hz single phase with externally mounted 75KVA step-up transformer E4502TB 50KW 240V 60Hz single phase E4502TC 50KW 480V 60Hz 3 phases E4502TD 65KW 480V 60Hz 3 phases E4502TE 80KW 480V 60Hz 3 phases	E4502SS E4502RL
	E4502WB	Eaton 93PM 150 kVA (seismic OSHPD)					
	E4582AF	Riello MHT 100 kVA three phase (non-seismic)					
	E4582AK	Riello UL UPS MHT 100 kVA, three phase, Seismic option					
Optima XR640 Discovery XR640*, Discovery XR650*	E4502WA	Eaton 93PM 150 kVA UPS (non-seismic)	*E4504FQ	0.7 kVA Partial System UPS (* indicates approval for use with these systems)	E4502WA/WB Configurations include their own MBP and a wall-mounted load distribution panel. Riello - offers a free standing and a wall-mounted panel E4582BG-Wall-mount E4582BL-Free- standing	E4502RP - 90 Amp, Auto Restart E4502ST- 80 Amp E4502RS - 110 Amp E4502RT- 150 Amp E4502JH - 225 Amp E4502RY - 125 Amp, Auto Restart	E4502SS E4502RL
	E4502WB	Eaton 93PM 150 kVA (seismic OSHPD)					
	E4582AF	Riello MHT 100 kVA three phase (non-seismic)					
	E4582AK	Riello UL UPS MHT 100 kVA, three phase, Seismic option					

Specifications

- All specifications are subject to change without notice
- The product and brand names herein are the trademarks or registered trademarks of their respective owners

Pricing

- Please call to obtain current pricing. All pricing and product availability is subject to change without notice
- Price invoiced will be the price in effect at the time of order entry
- Quotations available upon request

Blanket Purchase Orders

You can save time and money by ordering your consumable products with our Blanket Order program. Blanket orders must be scheduled for a year or more and a signed purchase order agreement must be on file. Contact us for additional details.

Restocking Fee

- Returns are subject to, but not limited to, a minimum 15% restocking fee
- Certain items, such as sterile and environmentally controlled products within this catalog, are non-returnable and nonrefundable unless defective and have been noted as such

Product Returns

- Immediately upon receipt, please inspect all deliveries for order accuracy and condition
- For products shipped in error, please obtain return authorization from the Accessories and Supplies Call Center within thirty (30) days of delivery
- Power Quality items are nonreturnable and nonrefundable

Contact Us for General Information and Warranty Terms

In U.S.

GE HealthCare
Accessories and Supplies Customer Support Center
P.O. Box 414, W-544
Milwaukee, WI 53202

Phone: (866) 281-7545 – opt 1, opt 2, opt 1, opt 2

Fax: (877) 279-6990

Online: www.gehealthcare.com/accessories

Email: gehcaccessorysales@ge.com

All other regions

Contact your local GE HealthCare Representative.

GE HealthCare is a leading global medical technology, pharmaceutical diagnostics, and digital solutions innovator dedicated to providing integrated solutions to make hospitals more efficient, clinicians more effective, therapies more precise, and patients healthier.

Learn more at www.gehealthcare.com.

GE HealthCare reserves the right to make changes in specifications and features shown herein, or discontinue the product described at any time without notice or obligation. Contact your GE HealthCare representative for the most current information and availability. Please visit www.gehealthcare.com. Data subject to change.

©2023 General Electric Company.

GE and the GE Monogram are trademarks of General Electric Company.

GE is a trademark of General Electric Company used under trademark license.

All other product names and logos are trademarks or registered trademarks of their respective companies.

JB00645US Rev. 09/24



GE HealthCare