

Medical Materials & Technologies 3M[™] Microfluidic Diagnostic Tape 9980 Single Coated Aluminum Tape



Product Description

3M[™] Microfluidic Diagnostic Tape 9980, consists of a 4 mil aluminum foil coated on one side with a pressure sensitive silicone adhesive. The tape is supplied on a clear fluoro-silicone coated polyester release liner. The product is designed for use in diagnostic medical devices such as test strips and lab-on-a-chip or other challenging applications such as PCR.

Features and Benefits

- Silicone adhesive
- Adheres to a wide variety of substrates
- Thermally conductive
- Low autofluorescence
- Low evaporation

Composition

- Designed for lab-on-a-chip and PCR
- Non-hemolytic
- Low extractables
- Non-toxic to mammalian cells

A Backing 4 mil (102 um) Aluminum Foil B: Adhesive 2 mil (51 um) Silicone adhesive C: Liner 2 mil (51 um) Clear fluoro-silicone coated polyester release liner

Roll Description	
Roll Length	Maximum 300 yd (274 m) ± 2%
Roll Width	Maximum 11.0 in (27.9 cm) ± 0.06 in (1.52 mm)
Note: Care material 6 in (152 mr	a) plastic core

Note: Core material 6 in (152 mm) plastic core.

Adhesion & Liner Release	
Adhesion to glass, 180° Peel	82 oz/in (9.0 N/cm) - minimum
Liner release, 90° Peel	60 gm/in (232 mN/cm) - maximum

Note: release specification at the time of production

Biocompatibility Testing

The adhesive used in product 9980 (with a thinner aluminum backing) has been subjected to the following safety evaluations through an outside laboratory.


Study Type	Test method	Standard	Result
Cytotoxicity	Agar overlay	ISO 10993-5	Not cytotoxic
Cytotoxicity	MEM Elution	ISO 10993-5	Not cytotoxic
Hemocompatibility	Direct contact	ISO 10993-4	Non-hemolytic
Hemocompatibility	Extracts	ISO 10993-4	Non-hemolytic

Integrated Emission Intensity

Samples were compared to known reference materials, quartz slide, borosilicate slide and 10 ppb quinine. Quinine sulfate was chosen due to its high purity and stability as a fluorescence standard reference material.

Sample	Integrated Emission Intensity/10 ⁶	
Quartz Slide	8.0	
Borosilicate Cover Slide	4.1	
3M 9980 Adhesive	11.0	
10 ppb quinine in 0.5 N sulfuric acid	59.6	

*Sum of emission intensities over the range (λ EX = 365 nm, λ EM = 450-650 nm)



Average Fluorescence Spectra

Recommended Storage Conditions & Shelf Life

Product as supplied in original packaging will maintain certified properties for a period of two years from date of manufacture when stored at room temperature 68-77 °F (20-25 °C).

Product and Safety Information: User is solely responsible for determining the suitability of 3M samples and products for the intended use including any necessary safety or toxicity assessment. 3M will provide Material Safety Data Sheets or equivalent and summary results of biocompatibility testing upon request. In every case before usi ng any product in full scale production users should conduct their own tests to determine to their own satisfaction whether the product is of acceptable quality and is suitable for their particular purposes under their own operating conditions. Notice: Nothing contained herein shall be construed to imply the nonexistence of any relevant patents or to constitute a permission, inducement, or recommendations to practice any invention covered by any patent, without authority from the owners of this patent.

Warranty Information: All statements, technical information and recommendations herein are based on tests 3M believes to be reliable, but the accuracy or completeness thereof is not guaranteed. 3M warrants only that products will meet 3M's specifications at the time of shipment to the customer. 3M does not offer any other warranty and does not warrant the performance, safety or such other characteristics of products in combination with other materials. 3M specifically DOES NOT warrant products for any intended or unintended uses (whether or not foreseeable); for compatibility or suitability with other components or compatibility with any methods of manufacture or conversion. The foregoing warranty is made in lieu of all other warranties, expressed or implied, including the implied warranties of merchantability, fitness for a particular purpose and freedom from non-infringement.

Limitation of Remedies: If products are proven not to meet 3M's specifications, the sole and exclusive remedy available and 3M's only obligation shall be, at 3M's option, to replace such quantity of Products which are proven out of specification or to refund the purchase price paid for Products.

Limitations of Liabilities: The remedies provided herein are exclusive remedies against 3M for any alleged or actual nonconformance to specifications or defect or other failure in products or for 3M's performance of its supply obligations. Under no circumstances is 3M liable for any direct, indirect, incidental, special or consequential damages (including lost profits) in any way related to the product under any theory of law including, but not limited to, negligence and strict liability.

Ordering Information

To place an order, call our Customer Service at: 800-742-1994 (U.S.). For all orders outside the United States, please contact your local country representative or check out 3M.com/MedTechFindaRep for your region's contact information.

To have a sales representative contact you, to request samples or clinical and safety summaries, please contact us at 3M HELPLINE 800-228-3957 (U.S.) or check out **3M.com/MedTechContactUs** for your region's contact information.

Visit our website: **www.3M.com/MedTech** for product and services information, news, events, new product highlights or to make a direct inquiry.



Medical Materials & Technologies 3M Center, Building 275-5W-05 St. Paul, MN 55144-1000 USA

Phone 1-800-228-3957 Web 3M.com/MedTech 3M is a trademark of 3M. Please recycle. Printed in U.S.A. © 3M 2023. All rights reserved. Effective September 2023