



ECHLIN®

Did You Know?

NAPA Echlin Vehicle Speed Sensors

What does a Vehicle Speed Sensor do?

The Vehicle Speed sensor or VSS measures transmission/transaxle output or wheel speed. The ECM uses this information to modify engine functions such as ignition timing, AF ratio, transmission shift points, and to initiate diagnostic routines.

Where are these sensors located?

The Vehicle Speed sensor is typically located at the transmission or transaxle.

Will a malfunctioning Vehicle Speed Sensor illuminate the check engine light or affect vehicle operation?


Yes, a faulty sensor can illuminate the MIL, and may cause numerous and varying drivability problems due to the number of tasks the sensor output is involved in.

What are the common causes of failure?

In addition to wear, these sensors may have metal contamination, gear damage, or exposure to water intrusion depending where the connector is located.

How to determine if these sensors are malfunctioning?

The PCM monitors the VSS for component malfunctions as well as circuit problems. The diagnostic codes range between P0500 and P0503. The VSS can be checked with a scan tool or undergo a resistance check.



Vehicle Speed Sensor
or Transmission
Input Speed Sensor

What makes NAPA Echlin Vehicle Speed Sensors the best.

- As a global manufacturer, NAPA Echlin has complete control of the manufacturing process from componentry to finished product for a trouble-free product
- 100% environmental, endurance and end-of-line testing for signal amplitude and polarity ensures consistent product reliability and performance



Ford
VSS306



GM
VSS237



Chrysler
TSS100



Toyota
VSS247



Honda
VSS625



Nissan
VSS704

**NAPA Echlin
LOOKS RIGHT. FITS RIGHT. PERFORMS RIGHT.**

THE BEAR IS BACK

