

STEP 1

Lift harness by back D-ring and straighten any twisted webbing.

With sub-pelvic strap behind you, hang harness on shoulders.

Center back D-ring between shoulder blades.

Back D-ring location can be adjusted as necessary to ensure proper placement.



STEP 2



Fasten chest strap.

For Quick-Connect Chest Strap, connect mating halves of buckle, ensuring that two halves are fully connected with both locking pawls engaged.



For Qwik-Fit™ Buckle, insert smaller rectangle buckle through larger rectangle buckle, and lay two pieces flat.

STEP 3

Reach between legs and wrap appropriate leg strap around each thigh.

Ensure that straps are not twisted or crossed. Connect leg strap buckles.

Adjust leg straps for snug comfortable fit; tuck any excess webbing into elastic keepers.



For Quick-Connect Buckles, connect mating halves of buckle; ensure that two halves are fully connected, with both locking pawls engaged.



For Qwik-Fit Buckles, insert smaller rectangle buckle through larger rectangle buckle, and lay two pieces flat.



For tongue buckles, insert the buckle tongue into leg strap grommet and tuck free end into keeper.

STEP 4

Adjust torso straps for snug, comfortable fit by pulling down on torso webbing ends.



Use web management keepers to stow any excess webbing.



STEP 5

Adjust chest strap for snug, comfortable fit.

Chest strap location can be adjusted up or down if necessary by sliding webbing through chest buckle. Proper chest strap location is at user's sternum.



Harness properly fitted and ready for use.



DONNING INSTRUCTIONS

EVOTECH™
FULL BODY HARNESS

The Latest in Harness Technology

MSA
The Safety Company