

**Operating Manual**

**MSA AUER SSR 30/100**

**MSA AUER SSR 30/100 B**

**EN 13794 K/20/S**



MSA AUER GmbH  
Thiemannstrasse 1  
D-12059 Berlin

Germany

© MSA AUER GmbH. All rights reserved

## Contents

<b>1</b>	<b>Safety Regulations .....</b>	<b>4</b>
1.1	Correct Use .....	4
1.2	Liability Information .....	5
1.3	Safety and Precautionary Measures .....	5
<b>2</b>	<b>Description .....</b>	<b>6</b>
2.1	Overview .....	6
2.2	Function .....	7
2.3	Marking .....	8
2.4	Demonstration and Training Device .....	8
<b>3</b>	<b>Use .....</b>	<b>9</b>
3.1	Important Escape Rules .....	9
3.2	Carrying the Device .....	10
3.3	Donning the Device .....	11
<b>4</b>	<b>Maintenance and Cleaning .....</b>	<b>14</b>
4.1	Maintenance Instructions .....	14
4.2	Return of Used Device .....	14
4.3	Tightness Test .....	15
4.4	Maintenance Intervals .....	16
4.5	Documentation .....	16
<b>5</b>	<b>Transport regulations .....</b>	<b>17</b>
<b>6</b>	<b>Disposal .....</b>	<b>17</b>
<b>7</b>	<b>Technical Data .....</b>	<b>17</b>
<b>8</b>	<b>Ordering Information .....</b>	<b>18</b>

# 1 Safety Regulations

## 1.1 Correct Use

The SSR 30/100 respectively the SSR 30/100 B self-rescuer are respiratory protection devices [chemical oxygen apparatus] for self-rescuing which are independent of the ambient atmosphere. They protect the wearer of the devices during escape from a dangerous ambient atmosphere or whilst waiting for rescue from poisonous gases, toxic particles and oxygen depletion. It is to be used exclusively for self-rescue under dangerous conditions and is not intended for long-term use.

The devices described in this operating manual are in accordance with Directive 89/686/EEC [PPE-Directive] and are tested and certified by DEKRA EXAM GmbH [Reference number 0158].

The device is developed for one mission, used devices must always be replaced, reuse is not permitted.



### Warning!

The device may only be used once and must never be reused. Used or opened devices must be replaced by new devices.

It is imperative that this operating manual be read and observed when using the product. In particular, the safety instructions, as well as the information for the use and operation of the product, must be carefully read and observed. Furthermore, the national regulations applicable in the user's country must be taken into account for a safe use.



### Danger!

This product is supporting life and health. Inappropriate use, maintenance or servicing may affect the function of the device and thereby seriously compromise the user's life.

Before use the product operability must be verified. The product must not be used if the function test is unsuccessful, it is damaged, a competent servicing/maintenance has not been made, genuine MSA spare parts have not been used.

Alternative use, or use outside this specification will be considered as non-compliance. This also applies especially to unauthorised alterations to the product and to commissioning work that has not been carried out by MSA or authorised persons.

## 1.2 Liability Information

MSA accepts no liability in cases where the product has been used inappropriately or not as intended. The selection and use of the product are the exclusive responsibility of the individual operator.

Product liability claims, warranties also as guarantees made by MSA with respect to the product are voided, if it is not used, serviced or maintained in accordance with the instructions in this manual.

## 1.3 Safety and Precautionary Measures



### Attention!

Chemical Oxygen Escape Devices used in mining may be subject to particular Mining-Regulations that are to be observed.

There is an ignition danger in case the device is destroyed and the oxygen generating chemical comes into contact with combustible substances, e.g. coal.

Also observe official regulations applicable in the country of use.



### Attention!

Defective devices must not be used!

Removed defect devices from service and return them to MSA for inspection.

## 2 Description

### 2.1 Overview




Fig. 1 Design of the device

A	Inhalation	4	Pressure relief valve
B	Exhalation	5	Waist belt
1	Breathing tube with mouthpiece	6	KO <sub>2</sub> -canister
2	Heat exchanger	7	Neck strap
3	Breathing bag	8	Nose clip

The device is contained in an enclosed and sealed sturdy stainless steel container.

The device includes a chemical canister with potassium hyperoxide [KO<sub>2</sub>], which is required for the regeneration of the exhaled air.

MSA	Description
-----	-------------

After inflating the breathing bag with the exhalation air the device is directly ready for use. During the escape, the device supplies the wearer with breathable air which is prepared in the KO<sub>2</sub> canister.

### **SSR 30/100**

The device is worn continuously on the belt.

### **SSR 30/100 B**

The device is worn in front of the chest with a special chest harness.

## **2.2 Function**

The device supplies the wearer with oxygen which is created from the chemical potassium hyperoxide [KO<sub>2</sub>]. In an emergency, the container is opened and the respiratory protection device is taken out.

The device has a closed breathing circuit. When in operation, the exhaled air is transferred into the chemical canister with the potassium hyperoxide. The potassium hyperoxide reacts with the humidity and the carbon dioxide of the exhaled air and, at the same time, creates oxygen and heat. The air for inhalation prepared in this way is fed into the breathing bag and is then inhaled again.

The amount of resulting oxygen depends on the intensity of respiration. Increased respiration [more carbon dioxide, more humidity] increases the formation of oxygen or vice versa.

When the device is used for breathing, the KO<sub>2</sub> canister warms up, as does the inhalation air, gradually. This is normal and indicates the correct operation of the device.

The end of oxygen supply is indicated by increase of the inhalation resistance.



#### **Warning!**

The device must only be opened for use!

Otherwise humidity from the ambient air can penetrate the open device and affect the performance.

Used or opened devices must be replaced by new devices.

## 2.3 Marking

The devices are classified according to EN 13794 and marked with the type [code letter] and nominal duration [minutes]. The type, nominal duration and referenced standard are marked on the device.

The device is marked as follows:

Device	Marking	
	upper side	bottom side
MSA AUER SSR 30/100	MSA AUER	SSR 30/100 EN 13794 K/20/S Serial No. Date of manufacture
MSA AUER SSR 30/100 B	MSA AUER	SSR 30/100 B EN 13794 K/20/S Serial No. Date of manufacture

## 2.4 Demonstration and Training Device

The demonstration and training device can be used for demonstration and practise of wearing and breathing without using a chemical canister. The inhalation air is taken from the ambient air and the exhalation air is expelled outside.

The demonstration and training device is comparable in size, weight, external construction, handling and breathing resistance to the emergency use devices.

To distinguish it from the emergency use devices, the demonstration and training device has marked blue.



For the demonstration and training device the breathing air is taken from the ambient atmosphere, i.e. training must be made in environments free from contamination.

### 3 Use

#### 3.1 Important Escape Rules

The device protects the wearer during escape from a dangerous ambient atmosphere. During the escape, the following rules must always be observed:

1. Stay calm!
2. Choose the shortest route to safe ambient air!
3. Breathe calmly! Extra air will be consumed if breathing is fast and irregular.
4. Do not damage or compress the breathing bag, otherwise lifesaving oxygen may be lost!
5. The mouthpiece must be tight between teeth and lips and be tightly enclosed with the lips.



The device must always be available for emergencies. The device can be put into operation with a few simple hand movements in about 20 seconds.

### 3.2 Carrying the Device

#### Carrying the SSR 30/100

- (1) Pull the waist belt through the belt loops.
- (2) Close the belt.

#### Carrying the SSR 30/100 B



#### Donning the Carrying Harness

- (1) Extend waist belt [front] and suspenders [rear] to full length.
- (2) Pull harness over the head.



#### Donning the Device

- (3) Attach device to snap hooks of harness.
- (4) Observe correct position of the device.
  - ▷ Container marking 'oben' [top] must be visible.
  - ▷ Locking latch faces to right.



#### Adjusting the Carrying Harness

- (5) Hook the suspenders at the rear into the waist belt.
- (6) Tighten the suspenders.
- (7) Tighten the waist belt.

### 3.3 Donning the Device

#### Donning the SSR 30/100



##### Opening the Container

- (1) Pull the locking lever in the direction of the arrow until the seal breaks and locking device falls off.



##### Pulling out

- (2) Grasp container cover with one hand.
- (3) Pull out the rescuer by the neck strap with the other hand.
  - ▷ If the cover falls away with the locking device, the rescuer will automatically unfold and be suspended by the mouthpiece plug.
- (4) Detach device from mouthpiece plug.



##### Fitting the Neck Strap

- (5) Take off the protective helmet, if used.
- (6) Place the neck strap around the neck.



### Inserting Mouthpiece

- (7) Place mouthpiece into mouth with flange of mouthpiece between teeth and lips.
- (8) Bite down on the two lugs.
- (9) Inhale through the nose.
- (10) Exhale into the device.
  - ▷ So the breathing bag is inflated.



### Fit Nose Clip

- (11) Grasp nose clip by rubber nipples, pull nose pads apart and fit them unto nose.



### Adjust Neck Strap and Tie Waist Belt

- (12) Adjust neck strap.
  - ▷ Ensure that the head is able to move freely.
- (13) Tie waist belt and tighten with knot.
- (14) Put the protective helmet on, if used.

## Donning the SSR 30/100 B



### Opening the Container

- (1) Pull the locking lever in the direction of the arrow until the seal breaks and locking device falls off.



### Inserting Mouthpiece

- (2) Place mouthpiece into mouth with flange of mouthpiece between teeth and lips.
- (3) Bite down on the two lugs.
- (4) Inhale through the nose.
- (5) Inflate breathing bag with exhalation air.



### Fit Nose Clip

- (6) Grasp nose clip by rubber nipples, pull nose pads apart and fit them unto nose.

## 4 Maintenance and Cleaning

### 4.1 Maintenance Instructions

To maintain readiness for use, the device must be inspected regularly, checked for integrity, tightness and, if necessary, cleaned [do not use metal brushes!]. Other maintenance measures are not required.

As the device contains a chemical which is sensitive to moisture, it is packed in an airtight container and is sealed at the factory.

The frequency of inspection depends on the device load [→ chapter 4.4].

For used and/or opened devices, the chemical canister must always be replaced, reuse is not permitted. Internal checks and any repairs to the devies are to be carried out by the MSA Customer Service or authorized service centers.

### 4.2 Return of Used Device

For return of used or opened devices, observe the following:

- Pack the device and components in the device containers only after they have cooled down and are dry.
- No organic substances must enter the chemical canisters [e.g. solvents, oils, etc.].
- Observe transport regulations [→ chapter 5].

If the complete device cannot be packed in the container, the following procedure is required:

- Remove the chemical canister from the device:
  - (1) Therefor loosen the clamp and remove the breathing bag and breathing tube.
  - (2) Pack the chemical canister inside the container and seal with the original locking assembly of the container.
    - ▷ Do not use finely cutted filling material.
- Place the other components of the device with the closed container in a carefully packed package.
- The components must be complete and undamaged.

#### 4.3 Tightness Test

The tightness test of the device is carried out using the MSA tightness tester for chemical oxygen breathing protection apparatus. Detailed descriptions of the structure, function, use and maintenance of the tightness tester can be taken from the relevant operating manual of the tightness tester [→ chapter 8].

The tightness test of the device is carried out as follows:

- (1) Push the device without any straps into the tightness tester in such a way that the cover points towards the door.
- (2) Close the door and lock.
- (3) Set timer to 90 s.
- (4) Create overpressure with the lever, i.e. push the lever downwards until it engages and start the timer at the same time.
- (5) After 30 seconds, cover the black pointer with the red pointer.
- (6) After a further 60 seconds, the timer signals the end of the test period. Then read the pressure difference between the red and the black pointers.

The device is tight if the black pointer remains in the prescribed pressure range and if the pressure difference is no more than 5 mbar.

**If the pressure drop is more than 5 mbar, the unit must be replaced.**

#### 4.4 Maintenance Intervals



National regulation must be observed, e.g. control interval according German Mining Regulation.

User specific conditions may require shorter intervals.

The service life depends on the type and kind of treatment to which the device were subjected.

Intervals <sup>1</sup>	Inspection
Before and after carrying	External visual check: Check, that the seal is intact and that there are no external damages on the device.
Annually	Tightness check <sup>2</sup>
After 3 years <sup>3</sup>	Tightness check <sup>2</sup> and complete check <sup>4</sup> of 3% of the representative population of devices which are carried along or stored on vehicles.
After 5 years <sup>3</sup>	Tightness check and complete check <sup>4</sup> of 3% of the population.
After 7 years <sup>3</sup>	Tightness check <sup>2</sup> and complete check <sup>4</sup> of 3% of the population.
After 9 years	Tightness check <sup>2</sup> and complete check <sup>4</sup> of 3% of the population.
After 10 years	Replace device, use no longer permitted.

1. The intervals are based on the date of manufacture [month/year] on the container. Devices manufactured in the same year are considered as "population" and should be combined for inspection.
2. Tightness test with tightness tester D1118845 or by MSA Customer Service.
3. It is recommended that a service contract with MSA Customer Service is made.
4. Complete check = Internal inspection and check. The result will decide whether the device can be used further.

#### 4.5 Documentation

MSA recommends keeping a file for each device where the serial numbers, the dates of manufacture and the dates and results of the inspections are recorded.

## 5 Transport regulations

Chemical oxygen devices are classified as Dangerous Goods under Class 5.1 with the designation and hazard label "5.1, 3356, oxygen generator, chemical". Regard packing group II.

Undamaged and unopened devices can be transported in the packing material supplied with the device or in a different approved method of packing.

Damaged and/or opened devices should be welded into a plastic bag and packaged as described in chapter 4.1.

Notes concerning the various transport methods can be taken from the EU safety data sheet.

## 6 Disposal

The chemical canister contains strong alkaline and oxidizing substances [potassium hydroxide, potassium carbonate and potassium hyperoxide].

For disposal local regulations are to be observed.

## 7 Technical Data

	SSR 30/100	SSR 30/100 B
Weight [total]	approx. 2.0 kg	approx. 2.4 kg
Weight [ready for use]	approx. 1.3 kg	approx. 2.2 kg
Dimensions	height: approx. 180 mm width: approx. 180 mm depth: approx. 100 mm	
Carrying mode	on belt	on the chest
Carrying mode [during use]	in front of chest	in front of chest
Storage conditions	Normal climate, temperature: 0°C to 50°C	
Temperature at start	0°C to 50°C	
Ambient temperature in use	-20°C to 50°C	
Temperature class	T1 to T3	
Service life	max. 10 years [without being used]	
Breathing resistance	Inhalation: 3 mbar Exhalation: 7 mbar	
Oxygen content	more than 21% by volume	
Carbon dioxide content	less than 1% by volume	

	SSR 30/100	SSR 30/100 B
Temperature of inhalation air		+30°C to +50°C
Service time		
at escape conditions	20 min [breathing volume 35 l/min]	
waiting for rescue <sup>1</sup>		up to 100 min [breathing volume 10 l/min]

1. The actual duration time may deviate from the service time in dependency on the breathing air volume. As such the duration time in relation to a breathing air volume of only 10 l/min [e.g. sitting and waiting for rescue while breathing from the device] extends up to 100 min.

## 8 Ordering Information

Description	Article No.
SSR 30/100	D1123701
SSR 30/100 B	D1123705
Demonstration and Training Device SSR 30/100 TR	D1123711
Demonstration and Training Device SSR 30/100 B TR	D1123712
Waist belt - SSR 30/100	D1113958
Shoulder Strap SSR 30/100	10029099
Carrying Harness - SSR 30/100 B	D1123940
Exchange Self-Rescuer SSR 30/100	D1123703
Tightness Tester for closed devices	D1118845
Leak-test Module for Tightness Tester	D1118322
Replacement Pictogram	10111642



# MSA in Europe

[ [www.msa-europe.com](http://www.msa-europe.com) & [www.msa-gasdetection.com](http://www.msa-gasdetection.com) ]

Northern Europe	Southern Europe	Eastern Europe	Central Europe
<b>Netherlands</b> <b>MSA Nederland</b> Kernweg 20 1627 LH Hoorn Phone +31 [229] 25 03 03 Fax +31 [229] 21 13 40 info@msaned.nl	<b>France</b> <b>MSA GALLET</b> Zone Industrielle Sud 01400 Châtillon sur Chalaronne Phone +33 [474] 55 01 55 Fax +33 [474] 55 47 99 message@msa-gallet.fr	<b>Poland</b> <b>MSA Safety Poland</b> ul. Wschodnia 5A 05-090 Raszyn k/Warszawy Phone +48 [22] 711 50 33 Fax +48 [22] 711 50 19 eer@msa-europe.com	<b>Germany</b> <b>MSA AUER</b> Thiemannstrasse 1 12059 Berlin Phone +49 [30] 68 86 0 Fax +49 [30] 68 86 15 17 info@auer.de
<b>Belgium</b> <b>MSA Belgium</b> Duwijkstraat 17 2500 Lier Phone +32 [3] 491 91 50 Fax +32 [3] 491 91 51 msabelgium@msa.be	<b>Italy</b> <b>MSA Italiana</b> Via Po 13/17 20089 Rozzano [MI] Phone +39 [02] 89 217 1 Fax +39 [02] 82 59 228 info-italy@ msa-europe.com	<b>Czech Republic</b> <b>MSA Safety Czech</b> Pikartská 1337/7 716 07 Ostrava-Radvanice Phone +420 [59] 6 23222 Fax +420 [59] 6 232675 info@msa-europe.cz	<b>Austria</b> <b>MSA AUER Austria</b> Kaplanstrasse 8 3430 Tulln Phone +43 [22 72] 63 360 Fax +43 [22 72] 63 360 20 info@msa-auer.at
<b>Great Britain</b> <b>MSA Britain</b> Lochard House Linnet Way Strathclyde Business Park BELLSHILL ML4 3RA Scotland Phone +44 [16 98] 57 33 57 Fax +44 [16 98] 74 0141 info@msabritain.co.uk	<b>Spain</b> <b>MSA Española</b> Narcís Monturiol, 7 Pol. Ind. del Sudoeste 08960 Sant-Just Desvern [Barcelona] Phone +34 [93] 372 51 62 Fax +34 [93] 372 66 57 info@msa.es	<b>Hungary</b> <b>MSA Safety Hungaria</b> Francia út 10 1143 Budapest Phone +36 [1] 251 34 88 Fax +36 [1] 251 46 51 info@msa.hu	<b>Switzerland</b> <b>MSA Schweiz</b> Eichweg 6 8154 Oberglatt Phone +41 [43] 255 89 00 Fax +41 [43] 255 99 90 info@msa.ch
<b>Sweden</b> <b>MSA NORDIC</b> Kopparbergsgatan 29 214 44 Malmö Phone +46 [40] 699 07 70 Fax +46 [40] 699 07 77 info@msanordic.se		<b>Romania</b> <b>MSA Safety Romania</b> Str. Virgil Madgearu, Nr. 5 Ap. 2, Sector 1 014135 Bucuresti Phone +40 [21] 232 62 45 Fax +40 [21] 232 87 23 office@msanet.ro	<b>European International Sales</b> [Africa, Asia, Australia, Latin America, Middle East] <b>MSA EUROPE</b> Thiemannstrasse 1 12059 Berlin Phone +49 [30] 68 86 55 5 Fax +49 [30] 68 86 15 17 contact@msa-europe.com
<b>MSA SORDIN</b> Rörläggvägen 8 33153 Värnamo Phone +46 [370] 69 35 50 Fax +46 [370] 69 35 55 info@sordin.se		<b>Russia</b> <b>MSA Safety Russia</b> Pokhodny Proezd, 14 125373 Moscow Phone +7 [495] 921 1370/74 Fax +7 [495] 921 1368 msa-moscow@ msa-europe.com	