

# TEC-CLAMP™ NEW DURABLE CLAMPING SOLUTION

Hooking-up tractor/trailer connection lines just got easier! The new 3 hole **TEC-CLAMP™** allows you to lock in your lines and go! No tools or hardware needed for fast, easy installations! Versatile design can be used with both rubber air hose or coiled tubing hook-ups.



US Pat. D722,867



Part No. 9888  
Stk. Code 47261  
with E-coated clip

• Stainless Steel or E-Coated clip options.  
For use with both Tender kit & Pogo Stick  
suspension devices

• Heavy duty clamp design. Superior  
strength and high performance in the most  
extreme application environments. A clear  
leader of the pack in clamping solutions.



Part No. 9888ST  
Stk. Code 47269  
with Stainless steel clip

• Easy to use aluminum  
locking clasp - No tools  
needed!

• Optional, red “power” tab provides  
maximum application versatility

• Corrosion resistant composite body

• Quick guide installation instructions  
embossed on clamp body

• “Hose Keeper” holds each line in place  
while installing the other lines



# TEC-CLAMP™ PARTS COVERAGE

## TEC-CLAMP™ PARTS COVERAGE

Part No.	Stk Code	Description
9888	47261	<b>TEC-CLAMP™</b> with E-coated clip
9888ST	47269	<b>TEC-CLAMP™</b> with Stainless steel clip
9888TAB	47270	Red "power" insert tab (10 pack)
94-0106	47271	E-Coated clip
94-0102	47067	Stainless steel clip



**Part No. 9888**  
**Stk. Code 47261**

## INSTALLATION GUIDE

### Step 1 OPEN TEC-CLAMP™ BY UNLATCHING THE ALUMINUM LOCKING CLASP



### Step 2 TEST CABLE FIT

- Place the cable in the center position labeled "power" and latch clamp
- Once you have determined if you need the red "power" tab remove cable - powercoil will be reinstalled in step 5



*Typically ABS (green) style cables with larger diameters will not require the red "power" tab. Standard black cables with smaller diameters may require red "power" tab.*

**CAUTION:** Ensure that you are not pinching or collapsing the cable by utilizing the red "power" tab. Use only as needed

### Step 3 SECURE FIRST AIRLINE INTO HOSE KEEPER LABELED "AIR-1"



### Step 4 INSTALL SECOND AIRLINE INTO HOSE KEEPER LABELED "AIR-2"



### Step 5 INSTALL POWER CABLE INTO MIDDLE SECTION LABELED "POWER"



### Step 6 CLOSE THE TEC-CLAMP™ AND LOCK CLASP



HANG CLAMP FROM APPROPRIATE SUSPENSION DEVICE USING ATTACHED CLIP



US Pat. D722,867