



A. Mesh Back  
QTY 1



B. Seat  
QTY 1



C. Mechanism  
QTY 1




D. Chair Arms  
QTY 2



E. Casters  
QTY 5



F. Base  
QTY 1



G. Cylinder  
QTY 1



H. M5 Wrench  
QTY 1



I. Screw 1/4\*\*46mm  
QTY 6



J. Screw 1/4\*\*1  
QTY 4



K. Screw 5/16\*\*3/4  
QTY 3



L. M4 Wrench  
QTY 1



M. Headrest  
QTY 1




N. Headrest part  
QTY 1




O. Screws  
QTY 2


**Step 1:** Attach the armrest (D) to seat (B) by use an M4 wrench (L) and six screws (I).




**Step 2:** Attach the mechanism (C) to seat (B) by use an M4 wrench (L) and four screws (J).




**Step 3:** Attach the backrest (A) to the mechanism (C) by use three screws (K) and M5 wrench (H).



**Step 4:** (OPTIONAL) If chair with headrest (M), attaching the headrest (M) to the back (A) by use the headrest positioning part (N), M4 wrench (L) and two screws (O).



**Step 5:** Finally, press casters (E) into base (F), attach the cylinder (G) to base (F) by using two people to lift the chair body onto the cylinder.



**Important:** This chair is to be used by one individual at a time. Please be sure to tighten all screws. Save the wrench and periodically tighten the screws when needed. Do not lean back on 2 wheels or use the chair as a stepladder. Use this chair for its intended purpose only.

CUSTOMER SERVICE HOTLINE  
800-626-6060