


BED

CORTECH




You will need:



1x

Pencil
For Marking Floor




1x

Drill
With 3/8 Bit



16x

3/8-16 x 3.75"
Security Torx Anchor Bolts



16x

Flat Washer

- 1.** Position bed on its back as to access the bottom of the bed.
- 2.** Select and drill all sixteen mounting locations on the bottom of the bed.
- 3.** Place bed right side up and locate where it is to be secured to the floor.
- 4.** Using a pen or pencil, mark mounting hole locations on the floor using the holes drilled in step 2.
- 5.** Move bed and drill holes in the sixteen locations where you marked the floor. Hole depth should be 2.0" deep MINIMUM.
- 6.** Replace the bed lining up the drilled holes with the holes in the floor.
- 7.** Place one flat washer over each of the sixteen anchor bolt and guide the bolts through the bed and into the holes into the floor.
- 8.** Tighten each anchor bolt 3-5 turns past finger tight.