


Positioning installation of the arm mechanism



- 1. Measure the depth of the desk or mounting surface.
- 2. Select position of the arm base using the template below.

	:	
0		0
0		ο
0		0
0		0
0		0
0		0
0		0
0		0
0	23.5 INCH	0
0	24.5 INCH	0
0	25.5 INCH	0
0	26.5 INCH	0
0	27.5 INCH	0
0	28.5 INCH	0
0	29.5 INCH	0
0	30.5 INCH	0
0	31.5 INCH	•)