

# workwell<sup>™</sup>





### The Reach LED Crane Lamp

WW01GB1 WW01WL1 WW01KD1

PL-0130

# **ENGLISH**

The Reach LED Crane Lamp

**CONGRATULATIONS!** Your new WorkWell by OttLite™ product brings you the finest in healthy lighting technology.

### **WARRANTY INFORMATION**

This product features a 5 year limited warranty. For more information visit: OttLiteWorkWell.com/warranty

### **LAMP ASSEMBLY WITH BASE**

WARNING: To prevent electrical shock, make sure the lamp is not plugged in until fully assembled per instructions.

- Remove all packing from the box and lay both lamp assembly and base on a solid surface such as a table.
- 2. Lift lamp assembly by lower body section (F) and fully insert dowel (D) into the stem (C) on the top of base (A).
- 3. Insert lock screw (B) through the recessed hole located in stem (C). Lock screw (B) can be tighten by hand turning clockwise until snug. NOTE: A screwdriver can also be used to tighten lock screw (B).
- Connect splitter cable (K) inputs (L) into lamp cord connections (M).
- **5.** Connect power adapter input (N) into lamp cord connection (O).
- Plug power adapter (P) into a standard household 120V AC outlet. NOTE: Only use with supplied power adapter to avoid damage or fire.

### **LAMP OPERATION**

- 1. Turn the lamp ON or OFF by depressing switch (E) located on the front-underside of the shade. Switch (E) controls the LED brightness level. This lamp "dims" from high to low. Press switch (E) continuously until desired brightness setting. NOTE: If dimmer function was employed prior to turning "OFF" lamp, the lamp will return to lamp setting last employed unless disconnected from adapter.
- To reposition the light, hold the base steady and grasp either lower body section (F) or upper body section (G) to position as desired. Lamp body can also rotate on base.
- 3. Shade (H) can rotate approximately 90 degrees left-right.
- 4. To increase tension in arm joints, twist selected knobs (R, S, T) clockwise by hand. DO NOT force knobs as they can strip.

**CAUTION:** The lamp is free to rotate on its base. **DO NOT** rotate the lamp such that the power cord begins to wind up.

# **SAFETY WARNING:** TO REDUCE THE RISK OF

FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

- 1. Turn lamp off and WAIT UNTIL LAMP HEAD (H) and ADAPTER (P) ARE COOL before handling.
- LAMP HEAD (H) might get hot after several hours of continuous use, DO NOT place your hands directly on the surface of lamp head.
- 3. Never use with an extension cord unless the plug can be fully inserted into the receptacles in the extension cord. Do not alter the plug. The lamp head included with this unit cannot be replaced by the consumer.

**NOTE:** The important safety instructions appearing in this instruction sheet are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution, and care must be used with any electrical product.

CAUTION! IF THE EXTERNAL FLEXIBLE CABLE OR CORD OF THIS LUMINAIRE IS DAMAGED, IT SHALL BE EXCLUSIVELY REPLACED BY THE MANUFACTURER OR ITS SERVICE AGENT OR A SIMILAR QUALIFIED PERSON IN ORDER TO AVOID A HAZARD. INDOOR USE ONLY.

# FCC PART 15

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that of the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

**CAUTION:** Any change or modification to product not expressly recognized by OttLite Technologies voids OttLite's responsibility for proper function of product.

### CAN ICES-005 (B)/ NMB-005 (B)

### AC/DC ADAPTER

Input: AC 100-240V, 50/60 Hz, 1.4A Output: 18V DC, 1.3A with a Male DC Plug

THIS LAMP CONTAINS a 5V-2.1A USB output port (Q) located on the base of the lamp. USB port can charge such items as tablets, smart phones, etc.

#### ACCESSORY:

2-in-1 Lightning and Micro USB cable (U) included is for charging purposes only. NOT FOR DATA TRANSFER.

INS170375 REV072517