










Hardware List (included in GC268CWB1)

	6PCS Machine Bolts(1-1/4")		2 PCS Metal Grommet
	2 PCS Keys For File Drawer Lock		2 PCS Long(1-1/4") Flat Head Wood Screws
	4 PCS Wood Dowels (ϕ8x25mm)		10 PCS Short (1") Flat Head Wood Screws
	4 PCS Metal-Shelf Clips		





GC268CWT Parts List

E	DESK TOP	1 PC
		

GC268CWB2 Parts List

B	PEDESTAL	1 PC
		


GC268CWB1 Parts List

A	PEDESTAL	1 PC	C	BACKPANEL	1 PC	D	CROSS BAR	1 PC	F	DROP FRONT CENTER DRAWER	1 PC
											


Notes: Need two people to assemble.

Instructions:


- ① Move the pedestals ① ② to the desired location , insert and tighten **machine bolts (1-1/4")**(6 PCS) to connect **backpanel ③** to the pedestals ① ②.
- ② Insert center **Cross Bar④** to the pedestals ① ② , tighten with **(1-1/4") flat head wood screws**(2 PCS).



3. Insert two **Wood Dowels** (4 PCS) in each Pedestal (A) (B).
4. Loosen the screw to adjust **Metal figure8** (10 PCS) of its direction of the panel and re-screw.




5. Insert **Short (1") Flat Head Wood Screws** (10 PCS) through metal figure 8 to connect Desk Top (E) and pedestals.



6. Install the Keyboard Pullout (F) to place .

Important:

(Be sure to move the ball bearing retainer all the way to the front of the glide and carefully slide the rails into the glides and ball bearing retainer.)



Assembly is now complete.