









Hardware List (included in GC268FB1)

	6 PCS Machine Bolts(1-1/4")		2 PCS Metal Grommet
	2 PCS Keys For File Drawer Lock		2 PCS Long(1-1/4") Flat Head Wood Screws
	4 PCS Wood Dowels (Ø8x25mm)		14 PCS Short (1") Flat Head Wood Screws





GC268FT Parts List

E	DESK TOP	1 PC
		

GC268FB2 Parts List

B	PEDESTAL	1 PC
		


GC268FB1 Parts List

A	PEDESTAL	1 PC	C	BACKPANEL	1 PC	D	CROSS BAR	1 PC	F	DROP FRONT CENTER DRAWER	1 PC
											


Notes: Need two people to assemble.

Instructions:


- ① Move the pedestals (A) (B) to the desired location , insert and tighten machine bolts (1-1/4") (6 PCS) to connect backpanel (C) to the pedestals (A) (B).
- ② Insert center Cross Bar (D) to the pedestals (A) (B), tighten with (1-1/4") flat head wood screws (2 PCS).





3. Insert two **Wood Dowels** (4 PCS) in each Pedestal (A) (B).
4. Loosen the screw to adjust **Metal figure8** (14 PCS) of its direction of the panel and re-screw.



5. Insert **Short (1") Flat Head Wood Screws** (14 PCS) through metal figure 8 to connect Desk Top (E) and pedestals.



6. Install the Keyboard Pullout (F) to place .
- Important:**
(Be sure to move the ball bearing retainer all the way to the front of the glide and carefully slide the rails into the glides and ball bearing retainer.)



Assembly is now complete.