



Merit[®] air conditioners offer these features:

Corrosion protection and galvanized steel cabinet's powder finish resist the elements for years to come

Proprietary cabinet design that makes them more durable and easier to install and service

All-Electric compatible with Lennox[®] air handlers

	Mid-Efficiency, Two-Stage Air Conditioner ML18XC2	Standard-Efficiency, Single-Stage Air Conditioner ML17XC1	Standard-Efficiency, Single-Stage Air Conditioner ML14XC1*
Energy Efficiency	Up To 17.8 SEER2	Meets or Exceeds 14.3 SEER2	Meets or Exceeds 13.4 SEER2
Quantum™ Coil	✓	✓	✓
Stages Of Cooling	Two-Stage Compressor	Single-Stage Compressor	Single-Stage Compressor
Sound Rating	As Low As 75 dB	As Low As 73 dB	As Low As 73 dB
ENERGY STAR [®] Certified ¹⁷	✓	✓	✓
Removes Humidity From The Home	Higher Removal Rate	High Removal Rate	High Removal Rate



FIND REBATES:

Visit www.lennox.com/buyers-guide/offers-and-savings/rebates.

* Available in the North Region only.

** Available in the North Region only, while supplies last.

For a full list of product details and warranty information, visit Lennox.com/terms-and-conditions.

Seasonal Energy Efficiency Ratio (SEER2)

This rating determines an air conditioner's efficiency. The higher the SEER2 rating, the more energy-efficient it is.

Quantum™ Coil

With years of rigorous testing under the most extreme conditions, our Quantum Coil—featuring a proprietary aluminum alloy exclusive to Lennox—is designed to weather the harshest elements.

All-Electric Compatibility

An HVAC system that pairs an electric air conditioner or heat pump with an electric air handler, eliminating the need for natural gas while helping to lower energy bills and reduce greenhouse gas emissions.

ENERGY STAR® Certified

HVAC equipment with the ENERGY STAR label meets or exceeds federal guidelines for energy-efficient performance.

Warranty Your Way™

For eligible Merit series models, homeowners have the opportunity to obtain the default 5-year parts only extension (for a total of 10-years parts only coverage) or, in lieu of that option, they have the opportunity to receive 3 years of labor coverage and 2 years of parts coverage (for a total of 3 years labor coverage and 7 years parts coverage). Other terms, conditions, and exclusions apply. For more information, visit www.Lennox.com/WarrantyYourWay.

How does single-stage, two-stage & variable-capacity work?




72°
Single-Stage

Unit is either on or off, creating wide temperature swings.



72°
Two-Stage

Unit runs at either low or high speed, using the lower speed 80% of the time.



72°
Variable-Capacity

Unit runs at low most of the time, using only the amount of energy necessary to meet comfort need.

